

Privileged EXEC Commands

This chapter contains all the Privileged EXEC commands used to administer the router. The Cisco 1020 does not have an unprivileged EXEC mode. The commands are presented in alphabetical order.

attach async

This Privileged EXEC command provides direct access to the modem attached to the async interface for purposes of configuration or testing.

attach async *port*

Syntax Description

port Specifies the async port to attach to, either 1 or 2.

Command Mode

Privileged EXEC

Usage Guidelines

This command is useful for configuring or testing modems or debugging chat scripts.

Related Commands

chat-script
clear interface
modem-def
modem-type

clear interface

To reset the hardware logic on an interface, use the **clear interface** privileged EXEC command.

clear interface *type number*

Syntax Description

type Specifies the interface type; it is one of the keywords listed in Table 2-1.

number Specifies the port.

Table 2-1 Clear Interface Type Keywords

Keyword	Interface Type
async	Async interface
ethernet	Ethernet interface

Command Mode

Privileged EXEC

Usage Guidelines

Use **clear interface async** *number* after changing its configuration, to have the new configuration take effect.

Example

The following example resets the interface logic on interface async 1:

```
clear interface async 1
```

clear startup-config

This command erases the configuration information stored in nonvolatile memory.

clear startup-config

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Usage Guidelines

Using this command followed by rebooting the router will erase all configuration information.

Related Commands

write network

configure network

configure

To enter global configuration mode, use the **configure** privileged EXEC command.

configure [**terminal** | **network**]

Syntax Description

terminal Executes configuration commands from the terminal.

network Executes the configuration commands stored in a file on a server.

Default

terminal

Command Mode

Privileged EXEC

Usage Guidelines

If you do not specify **terminal** or **network**, the communication server defaults to terminal. After you enter the **configure** command, the system prompt changes from `cs-name#` to `cs-name(config)#`, indicating that you are in global configuration mode. To leave global configuration mode and return to the privileged EXEC prompt, press **Ctrl-Z**.

Examples

In the following example, the communication server is configured from the terminal:

```
cs# configure
```

```
Enter configuration commands, one per line. End with CNTL/Z.
```

In the following example, the communication server is configured from the file *tokyo-config* at IP address 131.108.2.155:

```
cs1# configure network
```

```
IP address of remote host? 131.108.2.155
```

```
Name of configuration file? tokyo-config
```

Related Commands

show configuration

write terminal

copy flash tftp

To copy a system image from Flash memory to a network server using TFTP, use the **copy flash tftp** privileged EXEC command.

copy flash tftp

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Usage Guidelines

The copy of the system image can serve as a backup copy and also can be used to verify that the copy in Flash is the same as on the original file on disk.

Example

The following example illustrates how to copy a system image from Flash memory to a network server using TFTP:

```
Router# copy flash tftp
Remote host? jade
Name of configuration file to write? cs1020-1.1
Requesting tftp of cs1020-1.1 to host jade (192.168.1.70)
Sending csOS .....
Sending msgOSM .....tftp complete
```

Related Commands

copy tftp flash

copy tftp flash

To copy a system image into Flash memory using TFTP, use the **copy tftp flash** privileged EXEC command.

copy tftp flash

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Usage Guidelines

The communication server prompts for the address of the network server and TFTP filename. The entire copying process takes several minutes and will differ from network to network.



Caution If you have a bad image in Flash memory and try to boot from Flash, the communication server will attempt to boot from the net using RARP and TFTP.

Example

```
Router# copy tftp flash
Remote host? jade
Name of configuration file to read? cs1020-1.1
Requesting tftp of cs1020-1.1 from host jade (192.168.1.70)
Initializing File System
!
!   CS1020 Operating System Upgrade - Release 1.1
!
Downloading file csOS ..... 240356 bytes
!
!   CS1020 System Messages File
!
Downloading file msgOSM ..... 38847 bytes
!
! Predefined Modem initialization strings
!
tftp complete
```

Related Commands

copy flash tftp

debug ip packet

Use the **debug ip packet** privileged EXEC command to display general IP debugging information. The **no** form of this command disables debugging output.

debug ip packet *access-list-number*
no debug ip packet

Syntax Description

<i>access-list-number</i>	IP access list number that you can specify. If the datagram is not permitted by that access list, the related debugging output is suppressed.
---------------------------	---

Command Mode

Privileged EXEC

Usage Guidelines

If a communication session is closing when it should not be, an end-to-end connection problem can be the cause. The debug ip packet command is useful for analyzing the messages traveling between the local and remote hosts.

IP debugging information includes packets received, generated, and forwarded. ICMP and UDP packets generated on the router are not displayed.

Note Because the debug ip packet command generates a significant amount of output, use it only when traffic on the IP network is low so other users on the system will not be adversely affected.

debug ipx packet

Use the debug ipx packet privileged EXEC command to display information IPX packets received, transmitted, and forwarded. The no form of this command disables debugging output.

debug ipx packet *access-list-number*
no debug ipx packet

Syntax Description

access-list-number

IPX access list number that you can specify. If the datagram is not permitted by that access list, the related debugging output is suppressed.

Command Mode

Privileged EXEC

Usage Guidelines

This command is useful for learning whether IPX packets are traveling over a router.

debug ppp

To debug PPP, use the **debug ppp** privileged EXEC command. To turn off the debugging function, use the **undebug** command.

debug ppp negotiation

undebug ppp

Syntax Description

negotiation Debugs the PPP protocol negotiation process.

Default

Disabled

Command Mode

Privileged EXEC

dial

This command causes the router to dial out to a site specified by the **site** command as manual dial.

dial *site* [**view**]

Syntax Description

site the name of a site specified by the site command as manual.

view show the dial out as it happens, for debugging purposes.

Command Mode

Privileged EXEC

Usage Guidelines

This command is mostly used for testing new sites before changing them to on-demand or continuous. The site entry must be specified as manual to be used with the dial command.

Related Commands

debug ppp

site

exit

To exit any command mode or close an active terminal session and terminate the privileged EXEC, use the **exit** command at the system prompt.

exit

Syntax Description

This command has no arguments or keywords.

Command Mode

Available in all command modes

Usage Guidelines

When you enter the **exit** command at the privileged EXEC levels, the privileged EXEC mode is ended. Use the **exit** command at the configuration level to return to privileged EXEC mode. Use the **exit** command in interface and site modes to return to global configuration mode. You can also press Ctrl-Z from any configuration mode to return to privileged EXEC mode.

Example

The following example shows how to exit an active session.

```
Router# exit
```

Related Commands

logout

logout

To close an active terminal session and terminate the privileged EXEC, enter the **logout** privileged EXEC command at the system prompt.

logout

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Usage Guidelines

This command has the same function as the **exit** privileged EXEC command.

Example

The following example shows how to exit an active session:

```
logout
```

Related Commands

exit

ping

To check host reachability and network connectivity, use the **ping** privileged EXEC command.

ping [*address*]

Syntax Description

address IP address or hostname of system to ping.

Command Mode

Privileged EXEC

Usage Guidelines

The **ping** (packet internet groper) command sends up to three ICMP Echo Request datagrams to verify connectivity.

If the system cannot map an address for a host name, it will return an error message.

To abort a **ping** session, type **ping** with no argument.

reload

To reload the operating system, use the **reload** privileged EXEC command.

reload

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Usage Guidelines

The **reload** command reboots the system. The **reload** command is used after configuration information is entered into a file and saved into NVRAM.

Example

The following example illustrates how to enter the **reload** command at the privileged EXEC prompt:

```
Router# reload
```

Related Commands

write memory

show access-lists

To display the contents of all current access lists, use the **show access-lists** privileged EXEC command.

show access-lists [*access-list-number*]

Syntax Description

access-list-number (optional) Access list to display.

Command Mode

Privileged EXEC

Usage Guidelines

For information on how to configure access lists, refer to the chapter “Configuring IP” of the *Access and Communication Servers Configuration Guide*.

Related Commands

access-list

show arp

Use the **show arp** privileged EXEC command to display the entries in the ARP table for the router.

show arp

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

show hardware

Use the **show hardware** privileged EXEC command display the configuration of the system hardware, the software version and the names and sources of configuration files.

show hardware

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show hardware** command from a Cisco 1020:

```
Router #> show hardware
Access Server Software (Cisco 1020), Version 1.1
Compiled Wed 21-Dec-94 23:59

Router uptime is 2 minutes

Cisco 1020 (386SE-25) processor with 1024K bytes of memory.
1 Ethernet/IEEE 802.3 interface
2 async interfaces.
128K bytes of non-volatile configuration memory.
Serial Number 85900001
```

Table 2-2 describes significant fields shown in the display.

Table 2-2 Show Hardware Field Descriptions

Field	Description
Version 1.1	Always specify the complete version number when reporting a possible software problem. In the example output, the version number is 1.1.
Router uptime is	The amount of time the system has been up and running.
Cisco 1020	The remaining output shows the hardware configuration.

The output of the **show hardware** privileged EXEC command can also provide certain messages. If such error messages appear, report the complete text of this message to your technical support specialist.

show hosts

Use the **show hosts** privileged EXEC command to display the static list of host names and addresses.

show hosts

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

show interfaces

Use the **show interfaces** privileged EXEC command to display information on interfaces.

```
show interfaces [interface-type interface-number]
```

Syntax Description

- interface-type* Type of interface to be shown. See Table 2-3.
- interface-number* Port number to be shown. On the Cisco 1020 the port number of the interface can be 0, 1, or 2, depending on the type of interface. See Table 2-3.

Table 2-3 Interface Type Keywords

Keyword	Interface Type	Interface Numbers
ethernet	Ethernet IEEE 802.3 interface.	0
async	Asynchronous serial port.	1, 2

Command Mode

Privileged EXEC

Related Commands

interface

show interfaces brief

Use the **show interfaces brief** privileged EXEC command to display information on all active interfaces.

show interfaces brief

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show interfaces brief** command:

```
Router# show interfaces brief
ether0: flags=1016<IP_UP,IPX_UP,BROADCAST>
      inet 192.168.1.1 netmask fffffff0 broadcast 192.168.1.255
      ipxnet 000000F3 ipxframe ETHERNET_802.2 mtu 1500
ptp2: flags=10BD<IP_UP,IPX_UP,POINT_TO_POINT,COMPRESS>
      dest 192.168.200.1 netmask fffffff0 ipxnet 000000F2 mtu 1500
```

Table 2-4 describes the fields shown in the display.

Table 2-4 Show Interfaces Brief Field Descriptions

Field	Description
IP_UP	The interface is up and running the IP protocol.
IP_DOWN	IP is not in use.
IPX_UP	The interface is up and running the IPX protocol.
IPX_DOWN	IPX is not in use.
BROADCAST	The network is a broadcast network (Ethernet).
POINT_TO_POINT	The network is a point to point connection (Async).
SUSPENDED	This on-demand interface is available for use but does not have an active connection to the remote site.
LISTEN	RIP packets can be received but not sent.
PRIVATE	No routing information will be received or transmitted.
RIPSEND	RIP packets are sent but not received.
	If none of the above 3 flags are present, (LISTEN, PRIVATE, RIPSEND) RIP packets can both be sent and received.
inet	The IP address of this interface.
dest	The destination IP address if it is a point to point connection.
netmask	The netmask for "inet" or "dest."
broadcast	The broadcast address if this is an ethernet interface.

show interfaces brief

Field	Description
mtu	The maximum transmission unit for the interface.
ipxnet	The IPX network number for the interface.
ipxframe	The IPX frame type for the interface.

show ip route

Use the **show ip route** privileged EXEC command to display the current state of the routing table.

show ip route

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show ip route** command:

```
Router# show ip route
Destination          Netmask          Gateway          Flag Met  Interface
-----
0.0.0.0              0.0.0.0          192.168.200.1    NS     1    ptp2
192.168.1.0          255.255.255.0    192.168.1.1      NL     1    ether0
192.168.200.1        255.255.255.0    192.168.200.1    HL     1    ptp2
```

Table 2-5 describes the fields shown in the display.

Table 2-5 Show IP Route Field Descriptions

Field	Description
Destination	The remote host or network.
Netmask	The mask applied to an address when comparing it to this destination.
Gateway	The next hop towards the destination.
Flag	Locally defined: "H" - A host route. "N" - A network or subnet route. "S" - A static route. "L" - A route to a directly attached network or host. "D" - A dynamic route, learned via RIP. "C" - A route which has recently changed but not propagated via RIP yet. "O" - An obsolete route scheduled for deletion.
Met	The hop count to the destination, from 1 to 15.
Interface	Which network interface to use. On-Demand interfaces are numbered starting at ptp3, up to ptp98.

Related Commands

default routing

ip route

routing rip

show ipx route

To display the contents of the IPX routing table, use the **show ipx route** privileged EXEC command.

show ipx route

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show ipx route** command:

```
Router# show ipx route
Network      Gateway                               Flag Met Ticks Interface
-----
000000F3     000000F3:00000CC05036 NL      1    1 ether0
000000F2     000000F2:00000CC05036 NL      1    1 ptp2
000000F1     000000F2:00000C0A2E9A ND      2   20 ptp2
```

Table 2-6 describes the fields shown in the display.

Table 2-6 Show IPX Route Field Descriptions

Field	Description
Network	Identifies the remote network.
Gateway	The next hop towards the destination.
Flag	Locally defined: "N" - A network or subnet route. "S" - A static route. "L" - A route to a directly attached network or host. "D" - A dynamic route, learned via RIP. "C" - A route which has recently changed but not propagated via RIP yet. "O" - An obsolete route scheduled for deletion.
Met	The distance metric to the destination, from 1 to 15.
Ticks	The distance tick metric to the destination, from 1 to 65535.
Interface	Identifies which network interface to use. On-Demand interfaces are numbered starting at ptp3, up to ptp98.

Related Commands

ipx route
routing rip

show ipx servers

To list the IPX servers discovered through SAP advertisements, use the **show ipx servers** Privileged EXEC command.

show ipx servers

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show ipx servers** command:

```
Router# show ipx server

Server                      Svc  Network  Host                      Sock Hops Interface
-----
0800090DF6C383C2NPI0DF6C  30C  000000F3:0800090DF6C3:400C  1 ether0
NOVELL                     107  00001701:0000000000001:8104  2 ptp2
NOVELL                     4    00001701:0000000000001:0451  2 ptp2
pr1                        5F2  000000F3:00000CC05036:066B  0 Internal
```

Table 2-7 describes the fields shown in the display.

Table 2-7 Show IPX Servers Field Descriptions

Field	Description
Server	Name of the server.
Svc	Service being advertised.
Network	Network the host providing the service is on.
Host	Host providing the service.
Sock	Socket service is provided on.
Hops	Distance Metric to server.
Interface	Interface to use to reach server.

show memory

Use the **show memory** privileged EXEC command to show statistics about the router's memory.

show memory

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

show modem

This command displays the initialization information for the specified modem, or the list of known modems if no argument is specified.

show modem [*modem*]

Syntax Description

modem

Short name for the modem as defined by **modem-def** command.

Command Mode

Privileged EXEC

Related Commands

modem-def

modem-type

show site

This command displays the settings for the specified site. Passwords are not displayed.

show site *site*

Syntax Description

<i>site</i>	The name of a site defined by the site command.
-------------	--

Command Mode

Privileged EXEC

Related Commands

show sites

site

show sites

This command displays the list of configured sites.

show sites

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Related Commands

show site

site

show tcp

Use the **show tcp** privileged EXEC command to display the status of TCP connections.

show tcp

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

show users

Use the **show users** privileged EXEC command to display information about the active ports of the router. The information displayed includes the line number, connection name, and idle time.

show users

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

show version

Use the **show version** privileged EXEC command display the configuration of the system hardware, the software version and the names and sources of configuration files.

show version

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show version** command from a Cisco 1020:

```
Router #> show version
Access Server Software (Cisco 1020), Version 1.1
Compiled Wed 21-Dec-94 23:59

Router uptime is 2 minutes

Cisco 1020 (386SE-25) processor with 1024K bytes of memory.
1 Ethernet/IEEE 802.3 interface
2 async interfaces.
128K bytes of non-volatile configuration memory.
Serial Number 85900001
```

Table 2-8 describes significant fields shown in the display.

Table 2-8 Show Version Field Descriptions

Field	Description
Version 1.1	Always specify the complete version number when reporting a possible software problem. In the example output, the version number is 1.1.
Router uptime is	The amount of time the system has been up and running.
Cisco 1020	The remaining output shows the hardware configuration.

The output of the **show version** privileged EXEC command can also provide certain messages. If such error messages appear, report the complete text of this message to your technical support specialist.

systat

To display information about the active ports of the router, use the **systat** privileged EXEC command.

systat

Syntax Description

This command takes no arguments or keywords.

Command Mode

Privileged EXEC

Usage Guidelines

This command is a synonym for the **show users** command.

telnet

To start a Telnet connection, enter the **telnet** privileged EXEC command.

telnet *host* [*port*]

Syntax Description

host A host name or an Internet address.

port (Optional) Decimal TCP port number; the default is the Telnet server port (decimal 23) on the host.

Command Mode

Privileged EXEC

terminal monitor

To set the ability to display **debug** command output and system error messages to the current terminal, use the **terminal monitor** privileged EXEC command. Use the **terminal no monitor** command to disable this ability.

terminal monitor
terminal no monitor

Syntax Description

This command has no arguments or keywords.

Default

Disabled

Command Mode

Privileged EXEC

Example

The following example illustrates how to enable the system debugging messages on the local terminal screen:

```
terminal monitor
```

trace

Use the **trace** Privileged EXEC command to discover the IP routes the communication server's packets take when traveling to their destination.

trace [*destination*]

Syntax Description

destination (Optional) Destination address or host name on the command line.

Command Mode

Privileged EXEC

Usage Guidelines

The **trace** command works by taking advantage of the error messages generated by routers when a datagram exceeds its time-to-live (TTL) value.

The **trace** command starts by sending probe UDP datagrams with a TTL value of one. This causes the first communication server to discard the probe datagram and send back an error message. The **trace** command sends several probes at each TTL level.

The **trace** command sends out one probe at a time. Each outgoing packet may result in one or two error messages. A *time exceeded* error message indicates that an intermediate communication server has seen and discarded the probe. A *destination unreachable* error message indicates that the destination node has received the probe and discarded it because it could not deliver the packet.

The **trace** command terminates when the destination responds, when the maximum TTL is exceeded, or when the user interrupts the trace by typing **trace** with no arguments.

Common Trace Problems

Due to bugs in the IP implementation of various hosts and routers, the IP **trace** command might behave in odd ways.

Not all destinations will respond correctly to a probe message by sending back an *ICMP port unreachable* message. A long sequence of TTL levels with only asterisks, terminating only when the maximum TTL has been reached, might indicate this problem.

There is a known problem with the way some hosts handle an *ICMP TTL exceeded* message. Some hosts generate an *ICMP* message but they reuse the TTL of the incoming packet. Because this is zero, the *ICMP* packets do not make it back. When you trace the path to such a host, you might see a set of TTL values with asterisks (*). Eventually the TTL gets high enough that the *ICMP* message can get back. For example, if the host is six hops away, **trace** will time out on responses 6 through 11.

write network

To copy the current configuration information to a network server, use the **write network** privileged EXEC command.

write network

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Usage Guidelines

This command copies the current configuration to a server host on the network. You are prompted for a destination host and filename.

Example

The following example illustrates how to begin the prompts for writing configuration information to a network host:

```
Router# write network
Remote host? 131.108.1.111
Name of configuration file to write? Router-config
Writing Router-config !! [OK]
Router#
```

write terminal

To display the current configuration information on the terminal, use the **write terminal** privileged EXEC command.

write terminal

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Example

The following example illustrates how to display the current configuration information:

```
write terminal
```

Related Commands

configure