



Doc. No. 78-1836-01

Cisco 7505 Public Network Certification

This publication provides international agency compliance, safety, and statutory information for wide area network (WAN) interfaces for the Cisco 7505 router. This information is to be used in conjunction with the *Cisco 7505 Hardware Installation and Maintenance* publication and as an addendum to the *Router Products Getting Started Guide*. This publication also supplements information in the Fast Serial Interface Processor (FSIP) configuration note (Document Number 78-1147-xx) and the MultiChannel Interface Processor (MIP) configuration note (Document Number 78-1208-xx).

FSIP with E1-G.703/G.704 Port Adapter

The Cisco Systems FSIP with E1-G.703/G.704 port adapter is a chassis-mounted processor/interface card for use within a range of data communication (gateway and router) chassis supplied by Cisco Systems. The FSIP with E1-G.703/G.704 is a self-contained product that provides all of the hardware and software necessary to allow connection of Cisco Systems' chassis to digital leased line circuits (point to point) using CCITT recommendation G.703 operating protocols at speeds up to 2 Mbps. The FSIP with E1-G.703/G.704 is fully transportable between compatible *host* chassis. The choice of each compatible chassis has no effect on capabilities, functionality, or performance of the FSIP with E1-G.703/G.704.

The FSIP with E1-G.703/G.704 consists of the following subassemblies:

- FSIP card (Part Number 73-1126)
- E1-G.703/G.704 port adapter (Part Number 73-1197 [unbalanced] and 73-1190 [balanced])

The FSIP with E1-G.703/G.704 provides capacity for the installation of up to four E1-G.703/G.704 adapter cards providing a maximum of eight serial port connections. Each port can provide connection to 2-Mb leased lines. Combined, the FSIP and E1-G.703/G.704 adapter cards provide all of the hardware necessary for supporting leased line communications.

Each port on the E1-G.703/G.704 port adapter is presented as a 15-pin, D-type connector. Each port is configured at the factory to offer either 75-ohm termination impedance for unbalanced operation or 120-ohm termination impedance for balanced operation. The E1-G.703/G.704 port adapter cable used is dependent on the impedance configuration. Further configuration is not necessary.

Each adapter cable provides a D-type connector to the applicable standard interface connector. Custom adapter cables must be ordered as follows:

- 75-ohm, unbalanced adapter cable (Part Number 72-0818)
- 120-ohm, balanced adapter cable (Part Number 723-0819 or 72-0838)



Caution The E1-G.703/G.704 port adapter is approved by British Approvals Board of Telecommunications (BABT) to Oftel Technical Requirement OTR.001 with a port type of 2DS (telephony traffic carried) or 5C (non-telephony traffic carried), which allows connection to the public 2048-kilobits per second (kbps) network presented with a G.703 interface.

The E1-G.703/G.704 port adapter is not intended to be used in a home environment, due to possible radio interference it might cause.

The E1-G.703/G.704 port adapter should not be connected to cabling that would be required by European Standard/Normative EN60950:1992 to be equipped with over-voltage protection. Only cables supplied by Cisco Systems should be used.

The E1-G.703/G.704 port adapter maintains bit integrity between the Network Port and the FSIP.

The worst-case delay through the E1-G.703/G.704 port adapter is 125 microseconds (μ s).

Useful Information About Safety

Except for Australia, the following port is designated Safety Extra-Low Voltage (SELV) within the scope of EN60950:1992:

- E1-G.703/G.704 interface to FSIP

The FSIP contains SELV circuitry. Ensure that attachments at the interconnection ports of the apparatus are also SELV circuits. SELV circuits are so designed and protected that, under both normal conditions and a likely fault condition, the voltage that can be drawn is not hazardous.

Always disconnect the chassis from the power supply before removing any covers.

Always disconnect the host product chassis from any analogue telephone circuits, basic access, or primary access Integrated Services Digital Network (ISDN) before removing any covers.

Failure to install the FSIP with E1-G.703/G.704 in accordance with these instructions will invalidate the approval.

If you have any doubt as to how to safely install the FSIP with E1-G.703/G.704 correctly within a host chassis, seek advice from a qualified telecommunications engineer or your local Cisco Systems sales office.

Except in Australia, users are reminded that this port should only be connected to SELV ports on other equipment in accordance with EN60950 clause 2.3. The FSIP serial interface is designated a SELV port within the scope of EN60950:1992.

Do not work on the system or connect/disconnect cables during periods of lightning activity.

FSIP Power Requirements

This apparatus is intended for use when powered by the FSIP card. The power supply used to power the FSIP is approved to EN41003 and EN60950 producing a SELV output in accordance with EN60950 clause 2.3. The power requirement for the FSIP with E1-G.703/G.704 port adapters installed is 1300 milliamperes (mA) at +5 volts direct current (VDC).

It is important to ensure that the power drawn by the apparatus, together with any auxiliary apparatus, lies within the rating of the host power supply.

FSIP with 5-in-1 Port Adapter

The Cisco Systems FSIP with 5-in-1 port adapter assembly is a processor/interface card assembly for use within a range of data communication (gateway and router) chassis supplied by Cisco Systems Europe. The FSIP assembly is a self-contained product that provides all of the hardware and software necessary to allow connections of Cisco Systems' chassis to either digital leased line circuits (point to point) or to Packet Switched Public Data Networks (PSPDN).

The FSIP assembly is fully transportable between compatible host chassis. The choice of each compatible chassis has no effect on the capabilities, functionality, or performance of the FSIP assembly.

The FSIP assembly consists of the following subassemblies:

- Fast Serial Interface Processor (FSIP) card (Part Number 73-1126)
- 5-in-1 serial port adapter card (Part Number 73-1185)
- Route processor card (Part Number 73-0877)
- Switch processor card (Part Number 73-0895)

The FSIP card is a self-contained telecommunication device that provides up to four 5-in-1 serial port adapters providing a maximum of eight serial port connections. Each port can provide connection to leased lines on packet switched services of the type X.21, V.24, V.35, and V.36. Combined, the FSIP and 5-in-1 serial port adapter cards provide all of the hardware necessary for supporting PSPDN communications. The wide area network (WAN) operating software is resident on the route processor card.

Each port of the 5-in-1 serial port adapter is presented as a custom 50-way connector. The following port configurations are supported:

- X.21 port for connection to leased lines at up to 2048 kbps or X.25 packet-switched service at up to 64 kbps.
- X.24 port for connection to X.21 bis leased lines or X.25 packet-switched service at up to 19.2 kbps.
- V.35 port for connection to X.21 bis leased lines or X.25 packet-switched service at up to 64 kbps.
- V.36 port for connection to X.25 packet-switched service at up to 64 kbps.

The final configuration of each serial interface is dependent on the serial port adapter cable used. The FSIP incorporates cable sensing circuitry to detect the presence of a specific cable for each service. Further configuration is not necessary. Custom cables are supplied with the apparatus and are as follows:

- X.21 adapter cable (Part Number 72-0790)
- X.24 adapter cable (Part Number 72-0793)
- X.35 adapter cable (Part Number 72-0791)
- X.36 adapter cable (Part Number 72-0795)

Each cable provides adaption from a 50-way custom connector to the applicable ISO standard connector. The CE168 marking (shown in Figure 1) signifies that the 5-in-1 port adapter meets the European Directive 91/263/EC, and has been designed to NET1 and NET2 standards.

Figure 1 CE168 Marking



X.25 Support

X.25 packet-switched support is provided by the operating software resident on the route processor card. This software is designated as the Cisco FSIP, X.25 Version 2.0. This software provides both the link and packet level facilities of the FSIP assembly.

The operating software is accessed via a VT100 terminal connected to the console port of the route processor card. The settings of the terminal should be as follows:

- Baud: 9600
- Data bits: 8
- Parity: none
- Stop bits: 1

To boot the software, type the following command at the ">" prompt:

```
rommon> b f
```

(The software will now boot from Flash memory.)

Useful Information About Safety

The FSIP assembly contains Safety Extra-Low Voltage (SELV) circuitry. Ensure that attachments at the interconnection ports of the apparatus are also SELV circuits. (SELV circuits are so designed and protected that, under both normal conditions and a likely fault condition, the voltage that can be drawn is not hazardous.)

Always disconnect the chassis from the power supply before removing any covers.

Always disconnect the host product chassis from any analogue telephone circuits, primary access, or basic access ISDN (where applicable) before removing any covers.

Failure to install the FSIP assembly in accordance with these instructions will invalidate the approval.

If you have any doubt as to how to safely install the Cisco FSIP assembly correctly within a host chassis, please seek advice from a qualified telecommunications engineer.

Do not work on the system or connect/disconnect cables during periods of lightning activity.

FSIP Power Requirements

The power requirements of the FSIP card (with 5-in-1 serial port adapter cards installed) are as follows:

- +5 VDC/1300mA
- +12 VDC/210mA
- -12 VDC/0mA

The power requirements of the route processor card are as follows:

- +5 VDC/9100mA
- +12 VDC/50mA
- -12 VDC/0mA

The power requirements of the switch processor card are as follows:

- +5 VDC/10000mA
- +12 VDC/0mA
- -12 VDC/0mA

It is important to ensure that the power drawn by the apparatus, together with any auxiliary apparatus, lies within the rating of the host power supply.

PRI-MIP Port Adapter

The Cisco Systems PRI-MIP port adapter is a daughter card connected to a chassis-mounted processor/interface card (MIP) for use within a range of data communication (gateway and router) chassis supplied by Cisco Systems. The PRI-MIP is a self-contained product that provides all of the hardware and software necessary to allow connection of the Cisco 7505 to structured digital leased line circuits (point to point) using CCITT recommendation G.703/704 operating at 2 Mbps. The card can also be used on an open structured lease line; however, the framing cannot be disabled. The PRI-MIP is also NET5 compliant for use on Primary Rate ISDN circuits operating at 2 Mbps. The PRI-MIP is fully transportable between compatible host chassis. The choice of each compatible chassis has no effect on capabilities, functionality, or performance of the PRI-MIP.

The PRI-MIP consists of the following subassembly:

- PRI-MIP port adapter (Part Number 73-1191)

The PRI-MIP provides capacity for a maximum of two independent serial port connections. Each port can provide connection to 2-Mb leased lines or Primary Rate ISDN.

Each port on the PRI-MIP port adapter is presented as a 15-pin, D-type connector. Each port is configured at the factory to offer either 75-ohm termination impedance for unbalanced operation or 120-ohm termination impedance for balanced operation. The PRI-MIP port adapter cable used is dependent on the impedance configuration. Further configuration is not necessary. Each adapter cable provides a D-type connector to the applicable standard interface connector. Custom adapter cables must be ordered as follows:

- 75-ohm, unbalanced adapter cable (Part Number 72-0818)
- 120-ohm, balanced adapter cable (Part Number 72-0819 or 72-0838)

The PRI-MIP port adapter should not be connected to cabling that would be required by European Standard/Normative (EN)60950:1992 to be equipped with over-voltage protection. Only cables supplied by Cisco Systems should be used.

The PRI-MIP port adapter is approved to British Approvals Board of Telecommunications (BABT) OfTel Technical Requirement OTR.001 with a port type of 2DS (telephony traffic carried) or 5C (non-telephony traffic carried), which allows connection to the public 2048-kilobits per second (kbps) network presented with a G.703 interface.

The PRI-MIP port adapter maintains bit integrity between the Network Port and the MIP mother card.

The worst-case delay through the PRI-MIP port adapter is 125 microseconds (μ s).

When the PRI-MIP is configured for 120-ohm balance operation, the CE168 marking (shown in Figure 1 on page 4) signifies that this product meets the European Directives 94/821/EC and 94/796/EC. In the 75-ohm configuration, the PRI-MIP is in compliance with the UK national standard OTR 001.

Useful Information About Safety

Except for Australia, the PRI-MIP port is designated Safety Extra-Low Voltage (SELV) within the scope of EN60950:1992.

The PRI-MIP contains SELV circuitry. Ensure that attachments at the interconnection ports of the apparatus are also SELV circuits. SELV circuits are so designed and protected that, under both normal conditions and a likely fault condition, the voltage that can be drawn is not hazardous.

Always disconnect the chassis from the power supply before removing any covers.

Always disconnect the host product chassis from any analogue telephone circuits, primary access, or basic access Integrated Services Digital Network (ISDN) before removing any covers.

Failure to install the PRI-MIP in accordance with these instructions will invalidate the approval.

If you have any doubt as to how to safely install the PRI-MIP correctly within a host chassis, seek advice from a qualified telecommunications engineer or your local Cisco Systems sales office.

Note that the host chassis should be connected to earth ground during normal use.

Do not work on the system or connect/disconnect cables during periods of lightning activity.

PRI-MIP Power Requirements

The PRI-MIP port adapter card derives its power from the MIP mother card. The power supply used to power the apparatus is approved to EN41003 and EN60950 producing a SELV output in accordance with EN60950 clause 2.3. The power requirement for the PRI-MIP port adapters installed is 1 ampere (A) at +5 volts direct current (VDC).

It is important to ensure that the power drawn by the apparatus, together with any auxiliary apparatus, lies within the rating of the host power supply.

Installation Requirements

This section describes special installation requirements for the following assemblies:

- FSIP with E1-G.703/G.704 port adapter
- FSIP with 5-in-1 port adapter
- MIP with one or two E1 ISDN PRI ports (PRI-MIP port adapter card)

Where applicable, these assemblies are approved only for installation in a host and with host attachments, which are either **type approved** for such apparatus or covered by a **General Approval**. Except at the edge connector, which plugs into the host's expansion slot, clearance and creepage distances of X millimeters (mm) and Y mm, as listed in Table 1, must be maintained between the cards and other parts of the host including any other expansion cards fitted.

Creepage distance is defined as the minimum distance measured across the surface of an insulator, between two points (following the contour of the insulator). Clearance distance is defined as the minimum distance measured in air between two points (line of sight).


Table 1 Creepage and Clearance Distances Based on Voltage

Voltage Used or Generated by Other Parts of the Host or Expansion Card (Vrms ¹ or VDC ²)	Creepage (Y mm) ³	Clearance (X mm)
Up to 50	2.4 (3.8)	2.0
Up to 125	3.0 (4.8)	2.6
Up to 250	5.0 (8.0)	4.0
Up to 300 ⁴	6.4 (10.0)	4.0

- 1. Vrms = root mean square voltage.
- 2. VDC = volts direct current.
- 3. The creepage distances not in parentheses apply when the equipment is installed in a normal office environment. The larger dimensions, given in parentheses, must be applied when the equipment is installed in an environment in which dust and other types of pollution could conduct electricity because of the effects of dampness and condensation. This applies to locations subject to high humidity.
- 4. For working voltages exceeding 300V, consult a competent telecommunications engineer prior to installation.

Clearance and creepage distances are measured between adjacent parts, as shown in Figure 2.

Figure 2 Creepage and Clearance Distance Measurements



Note that in Figure 2, X indicates the clearance distances between the cards and between adjacent cards and components, and Y shows the creepage path across the surface of an insulator and between the two points indicated by X.

For European Community (E.C.) Use Only

The following operating conditions are required within the European Community:

The ports marked “Ethernet,” “10BaseT,” “TokenRing,” “FDDI,” “Console,” and “AUX” are SELV circuits. SELV circuits should only be connected to other SELV circuits.

The ports marked “Ethernet,” “10BaseT,” “TokenRing,” “FDDI,” “Console,” and “AUX” have a safety warning applied to them as follows:

“These ports do not provide isolation sufficient to satisfy the requirement of EN60950:1992; apparatus connected to these ports should either have been approved to EN60950:1992 or have previously been evaluated against plc (Post Office) Technical Guides 2 or 26 and given permission to attach; any other usage will invalidate any approval given to this apparatus.”

Connection of power supply: the Cisco 7505 is intended for use when supplied with AC power from a supply providing 100 through 240 VAC, 50 through 60 Hz, 9 through 4A or when supplied with DC power from a supply rated 40 through 72 VDC, 20 through 16A.

Other usage will invalidate any approval given to this apparatus if as a result it ceases to comply with EN60950:1992.

Agency Approvals for the Cisco 7505

- Safety: UL 1950, CSA 22.2-950, and EN60950, EN41003, TS001, AS/NZS3260
- Cisco 7505 FSIP with 5-in-1 adapter: EMI: FCC Class A, EN55022 Class B, VCCI Class 2
- Cisco 7505 FSIP with E1-G.703/G.704 adapter: EN55022 Class A
- Cisco 7505 MIP with E1: EN55022 Class B
- The CE168 marking (shown in Figure 3) signifies that the 7505 chassis meets the following European Directives: 73/23/EEC and 89/336/EEC.

Figure 3 CE Marking



Cisco Information Online

Cisco Information Online (CIO) is Cisco Systems' primary, real-time support channel. Maintenance customers and partners can self-register on CIO to obtain additional content and services.

Available 24 hours a day, 7 days a week, CIO provides a wealth of standard and value-added services to Cisco's customers and business partners. CIO services include product information, software updates, release notes, technical tips, the Bug Navigator, configuration notes, brochures, descriptions of service offerings, and download access to public and authorized files.

CIO serves a wide variety of users through two interfaces that are updated and enhanced simultaneously—a character-based version and a multimedia version that resides on the World Wide Web (WWW). The character-based CIO (called "CIO Classic") supports Zmodem, Kermit, Xmodem, FTP, Internet e-mail, and fax download options, and is excellent for quick access to information over lower bandwidths. The WWW version of CIO provides richly formatted documents with photographs, figures, graphics, and video, as well as hyperlinks to related information.

You can access CIO in the following ways:

- WWW: <http://www.cisco.com>
- Telnet: [cio.cisco.com](telnet://cio.cisco.com)
- Modem: From North America, 408 526-8070; from Europe, 33 1 64 46 40 82. Use the following terminal settings: VT100 emulation; data bits: 8; parity: none; stop bits: 1; and baud rates up to 14.4 kbps.

For a copy of CIO's Frequently Asked Questions (FAQ), contact cio-help@cisco.com. For additional information, contact cio-team@cisco.com.

Note If you are a network administrator and need personal technical assistance with a Cisco product that is under warranty or covered by a maintenance contract, contact Cisco's Technical Assistance Center (TAC) at 800 553-2447, 408 526-7209, or tac@cisco.com. To obtain general information about Cisco Systems, Cisco products, or upgrades, contact 800 553-6387, 408 526-7208, or cs-rep@cisco.com.

This document is to be used in conjunction with the *Cisco 7505 Hardware Installation and Maintenance* publication. (1836pnc5.fm)

Access Without Compromise, Catalyst, CD-PAC, CiscoFusion, Cisco Internetwork Operating System, Cisco IOS, CiscoView, CiscoWorks, HyperSwitch, LAN²LAN, LAN²LAN Enterprise, LAN²LAN Remote Office, LAN²PC, LightStream, Newport Systems Solutions, PC²LAN/X.25, Point and Click Internetworking, SMARTnet, SynchroniCD, *The Packet*, UniverCD, WNIC, Workgroup Director, Workgroup Stack, and XCI are trademarks; Access by Cisco and Bringing the power of internetworking to everyone are service marks; and Cisco, Cisco Systems, the Cisco logo, EtherSwitch, and Kalpana are registered trademarks of Cisco Systems, Inc. All other trademarks, service marks, registered trademarks, or registered service marks mentioned in this document are the property of their respective owners.

Copyright © 1995, Cisco Systems, Inc.
All rights reserved. Printed in USA
954R