



CISCO SYSTEMS

Doc. No. 78-1897-01

Cisco 7513 Chassis Replacement Instructions

Product Numbers: CHAS-7513-DC=, CHAS-7513-AC=, and MAS-7513=

This document provides instructions for replacing the Cisco 7513 chassis, which is available as a spare part.

Note Through this document, the term *the chassis* is be used to refer to the Cisco 7513 chassis.

The chassis is available as a spare part, and includes all of the components required for operation except the processor modules and power supplies (MAS-7513=), or as a spare with power supplies (CHAS-7513-DC= or CHAS-7513-AC=).

After you replace the chassis, you must move the processor modules from your old chassis into your new chassis.

The replacement chassis does not include the cable-management or rack-mounting hardware kits. You can move the rack-mounting hardware and cable-management bracket from the existing chassis, or order either kit as a spare part, which will ship with installation instructions.

The sections in this document include the following:

- What Is the Cisco 7513?, page 2
- Prerequisites, page 3
- Replacing the Chassis, page 7
 - Replacing a Rack-Mounted Chassis, page 8
 - Installing the Cable-Management Bracket, page 12
 - Moving Processor Modules from the Old Chassis to the New Chassis, page 13
 - Checking the Installation, page 17
 - Verifying the Installation Using show Command Descriptions and Examples, page 19
- Cisco Information Online, page 22

What Is the Cisco 7513?


The Cisco 7513 is a 13-slot router chassis, which uses the RSP2 and CxBus and CyBus interface processors. The chassis provides up to eleven interface processor slots. Although the chassis uses two high-speed, 1.067-gigabit-per-second (Gbps) CyBuses, it can accommodate all CxBus-based interface processors.

Any combination of network interface types is supported: Ethernet, Token Ring, Fiber Distributed Data Interface (FDDI), channel attachment, multichannel, serial, and so forth. The RSP2 and interface processors are keyed with guides on the backplane to prevent them from being fully inserted in the wrong slot.

Figure 1 shows the interface processor end of the Cisco 7513, which provides access to the thirteen slots, the system blower, and the power supplies. When facing the interface processor end of the chassis, the RSP2 is installed in RSP slot 6 or 7.

The eleven interface processor slots are numbered from slot 0 (far left) through slot 5 (CyBus 0) and slot 8 through slot 12 (CyBus 1).

Figure 1 Cisco 7513—Interface Processor End



Prerequisites

Before you begin this installation, review the safety guidelines in this section to avoid injuring yourself or damaging the equipment. This section also provides a list of the tools that you need to perform this replacement.

Safety Guidelines

The following guidelines will help to ensure your safety and protect the equipment. These guidelines are not inclusive of all potentially hazardous situations, so *be alert*.

General Safety Precautions

The following are general precautions for any workplace:

- Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.
- Do not work alone when potentially hazardous conditions exist.
- Do not wear loose clothing, jewelry (including rings and chains), or other items that could get caught in the chassis. Fasten your tie or scarf and sleeves.
- Never install equipment that appears damaged.
- Keep tools and chassis components away from walk areas.
- Practice good housekeeping; keep tools and parts clean, accessible, and in good working order.

Safety with Electricity

Follow these guidelines when working with any electrical equipment:

- Before beginning any procedures requiring access to the chassis interior, locate the emergency power-off switch for the room in which you are working.
- Disconnect all power and external cables before moving a chassis.
- Never assume that power has been disconnected from a circuit; always check.
- Carefully examine your work area for possible hazards such as moist floors, ungrounded power extension cables, and missing safety grounds.

In addition, use the guidelines that follow when working with any equipment that is connected to telephone wiring or other network cabling:

- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

Lifting Safely

A fully configured chassis weighs approximately 160 pounds (72.6 kilograms [kg]). Before installing the new (replacement) chassis, ensure that your site is properly prepared, so you can avoid having to move the chassis later to accommodate power sources and network connections.

- Never try to lift an object that is too heavy for you to lift safely by yourself.
- Ensure that your footing is solid, and balance the weight of the object between your feet.
- Lift the object slowly; never move suddenly or twist your body as you lift.
- Keep your back straight and lift with your legs, not your back. If you must bend down to lift the chassis, bend at the knees, not at the waist, to reduce the strain on your lower back muscles.
- When lifting the chassis, grasp the underside of the chassis exterior with both hands. Do not attempt to lift the end of the chassis with the handles on the interface processor carriers; these handles are not designed to support the weight of the chassis.
- Always disconnect all external cables before lifting or moving the chassis.

Preventing Electrostatic Discharge Damage

Electrostatic discharge (ESD) damage, which can occur when electronic boards or components are handled improperly, can result in complete or intermittent failures. Each processor module consists of a printed circuit board that is fixed in a metal carrier. EMI shielding, connectors, and a handle are integral components of the carrier. Handle processor modules by the metal frame or carrier only; avoid touching the board (particularly avoid touching any components, connector pins, or the metal *fingers* on the edge connector).

Following are guidelines for preventing ESD damage:

- Always use an ESD wrist strap or ankle strap and ensure that it makes good skin contact.
- When removing or installing interface processors, connect the equipment end of the ground strap to the chassis ground screw on the interface processor end of the chassis.
- Place removed processor modules board-side-up on an antistatic mat or in a static shielding bag.
- If you are returning a replaced part to the factory, immediately place it in a static shielding bag to avoid ESD damage to the board.
- Avoid contact between the board and clothing. The ESD strap only protects the board from ESD voltages on the body; ESD voltages on clothing can still cause damage.



Caution For safety, periodically check the resistance value of the antistatic strap. The measurement should be between 1 and 10 megohms.

Cable Strain Relief

If possible, position the new replacement chassis close enough to the existing system so that you can avoid having to disconnect power and interface cables. Be sure to disengage any strain relief devices before attempting to pull the cables from the port. Following are descriptions of the different methods of strain relief that are used on the AC-input and DC-input power cables and the various types of network interface cables:

- On the AC power input receptacle (on the interface processor end of the AC-input powered chassis), a cable retention band snaps up around the plug on the power cable to prevent it from being inadvertently pulled out of the receptacle.
- On the DC-input power supply, nylon cable ties are used to fasten the power cable to a bracket located just to the right of the input terminal block. Carefully cut these cable ties before you disconnect the power cable leads from the terminal block; replace the cable ties after you install the new chassis, and wire the power cable leads to the terminal block.
- Serial interface cables (all types) use thumbscrews on the cable connectors that secure the cable to the Fast-Serial Interface Processor (FSIP) port.
- Ethernet interface cables use either slide-type locks or thumbscrews. Although all Ethernet Interface Processors (EIPs) ship from the factory with slide-type locks on each port, all EIPs also include conversion kits for replacing the slide-type locks with jackscrews to accommodate Ethernet interface cables with thumbscrews.
- Multimode, FDDI connectors use small plastic arms on two sides of the connector that act like springs and are constrained by the inside of the connector port. To remove a multimode cable from an FDDI Interface Processor (FIP) port, pinch the two plastic arms inward while pulling the connector out of the port.

When removing any cable, pull the cable out at the connector; never pull or tug on the cable itself. For detailed descriptions of the system components, refer to the *Cisco 7513 Hardware Installation and Maintenance* publication.

Preparing the Work Area

Although some network downtime is unavoidable while you remove the RP and SP (or SSP) or RSP1 from their respective chassis, and replace them in the new chassis, you can minimize the downtime by placing the old and new chassis close together. If your existing chassis is mounted in a rack and there is space in the same rack or another rack close by, we recommend that you install the new, empty chassis in the rack before moving the components. (A fully configured chassis weighs approximately 160 pounds.)

Before installing the chassis in a new rack location, ensure that routing the interface cables to the new positions will not strain or tangle them.

You can further minimize downtime by leaving interface cables attached when you move interface processors to the new chassis, provided that doing so will not strain the cables.

Leave network interface cables connected to the interface ports *only* if the following conditions are true:


- You are able to place the new chassis close to the existing chassis, *and* moving the processor modules to the new chassis will not strain the interface cables.
- The new chassis is already located in its permanent location, *or* you will need to move it only a few feet into the space vacated by the old chassis when it is removed.

Note If these conditions are not true, for instance, if you must remove a rack-mounted chassis before you can install the new chassis, you *must* disconnect all power and network interface cables.

Also, ensure that your new chassis allows sufficient clearance for maintenance—to remove and replace processor modules, the blower module, and interface cables at the interface processor end, and to access the internal components at the noninterface processor end.

Figure 2 shows the chassis footprint and the clearance required.

Figure 2 Chassis Footprint and Clearance Requirements for Maintenance



Tools and Parts Required

This section lists the tools and parts you will need to complete these replacement procedures. Have the necessary tools on hand so that you can complete the replacement without interruption:

- To replace the chassis cover, you need a 3/16-inch, flat-blade screwdriver to loosen the captive screws on the chassis cover panel
- To install a replacement chassis, you need a number 1 Phillips and a 3/16-inch, flat-blade screwdriver for the captive installation screws on the processor modules (most of the carriers use slotted screws, but some use Phillips screws)
- To install a new cable-management bracket or to move the bracket from the existing chassis, you need the following tools and parts (panhead screws are included with the brackets):
 - Number 1 Phillips screwdriver
 - Cable-management bracket
 - Two M3 x 8-mm, Phillips panhead screws
- If you plan to mount or replace the chassis in an equipment rack, you also need the following tools:
 - Number 2 Phillips screwdriver
 - 1/4-inch and 3/16-inch, flat-blade screwdrivers
 - the ACS-7000RMK(=) rack-mount kit (with hardware) for the chassis (this kit also works for the Cisco 7000 chassis)
- Whenever you remove or install processor modules, have the following equipment on hand to help prevent ESD damage:
 - Antistatic mat or antistatic foam pad in case you need to put one of the processor modules down
 - Your own ESD-preventive strap or the disposable ESD strap that is included with all spares

Replacing the Chassis

The Route Switch Processor (RSP2) is a required system component and should only be removed when the system is not operation, although power can be on to the chassis. All interface processors support online insertion and removal (OIR); however, after installing an interface processor on line, you must wait at least 15 seconds for the system to reinitialize the interfaces before installing the next interface processor. Therefore, it is more efficient to leave the power off until all components are moved into the new chassis, then start up the system and check the entire installation.

If you are installing the new chassis in an equipment rack, proceed to the next section. Otherwise, proceed to the section “Installing the Cable-Management Bracket” on page 12.

Replacing a Rack-Mounted Chassis

This section describes how to replace a chassis that is installed in an equipment rack. The order in which you remove the existing system, install the new chassis, and replace the components will vary depending upon the space available in the rack and in the work area.

Some rack configurations, such as an enclosed rack or a rack with a power strip that limits access, prohibit the normal installation sequence of first installing the chassis in the rack and then installing the cable-management brackets before installing the processor modules. In these situations, you can move all the components into the new chassis before installing it in the rack, but ensure that you follow the safety guidelines for lifting and working with electrical equipment that are provided in the section “Safety Guidelines” beginning on page 3.

If there is sufficient space available in the same rack (or an adjacent rack) and you have a rack-mount kit available, you can install the new (replacement) chassis before you remove the existing system. You can minimize downtime and avoid having to disconnect network interface cables by leaving the existing system operating while you install the empty replacement chassis in the rack. Also, an empty chassis is significantly lighter and easier to handle than one that is fully configured. Just ensure that both chassis, when installed, will be close enough to avoid straining the interface cables connected to the interface processors.

If you must remove the existing system to make room for the replacement chassis, or if you need the existing rack-mounting hardware to mount the new chassis, you will have to disconnect all network interface cables before removing the existing system from the rack. You can leave the system components in the old chassis until after you install the new, empty chassis in the rack.

Assess your rack and lab configuration and the equipment you have available, then choose the appropriate replacement procedure from the following:


- If you have a spare rack-mount kit available and are able to install the new, empty chassis before you shut down and remove the existing one, follow the installation instructions provided with the rack mount kit, *Cisco 7513 Rack-Mount Kit Installation Instructions* (Document Number 78-2023-xx). After you install the new chassis in the rack and install the cable-management brackets, proceed to the section “Moving Processor Modules from the Old Chassis to the New Chassis,” on page 13, to move the components. (After you complete the replacement and check the installation, you will be directed to the following section, “Removing the Existing Chassis from the Rack,” to remove the empty chassis.)
- If you must remove the existing chassis before you can install the new one, proceed to the following section, “Removing the Existing Chassis from the Rack.”

Removing the Existing Chassis from the Rack

Before removing the existing chassis from the rack, you must shut down the system power and disconnect the power cable and all interface cables. To help avoid problems when you install the new chassis, label all interface cables with their slot/port address and mark the positions of the chassis ears (with tape, chalk, or a marker) so that you can install the new chassis in the same position.

Two chassis ears hold the chassis in the rack (see Figure 3), but do not bear the weight of the chassis. The ears are secured to the chassis sides and to the rack posts. The chassis is supported by the two rack brackets.

Figure 3 Chassis, Rack Brackets, and Ears



We recommend that two people perform this procedure: one person should support the chassis while the other person removes the screws that secure the ears to the rack.

Follow these steps to remove the existing chassis from the rack:


- Step 1** Turn OFF the system power and disconnect the power cable and all interface cables from the chassis.
- Step 2** Use a screwdriver to loosen and remove each of the four screws (two on each side) that secure the chassis ears to the rack rails.

Step 3 Pull the chassis out of the rack and place it on the floor or a table.



Warning The chassis weighs approximately 75 pounds with just the blower module and card cage installed. To prevent injury, have someone help you lift the chassis, as shown in Figure 4. To prevent damage to the air intake vent below the card cage, *do not* lift the chassis by grasping the handle with one hand and the bottom of the card cage with the other. Grasp the chassis, as shown in Figure 4.

Figure 4 Lifting the Chassis



This completes the chassis removal procedure.

If you have not yet installed the new chassis in the rack, proceed to the next section.

Installing the New Chassis in the Rack

Mount the chassis in the rack before connecting any interface or power cables. If possible, install the new, empty chassis in the rack first, then install the system components from the old chassis. To mount the chassis, install the ears on the chassis first, place the chassis in the rack, and then secure the ears to the rack rails.

We recommend that two people perform this procedure. Before lifting the chassis, ensure that your path to the rack is unobstructed.


Follow these steps to install the chassis in the rack:

Step 1 *Two people are required to perform this step.* With a person positioned at either side of the chassis, grasp the bottom edge of the chassis with one hand near the front and the handle on the side of the chassis with the other, as shown in Figure 4.

Step 2 Grasping the chassis as shown in Figure 4, slowly lift the chassis in unison. To prevent injury, avoid sudden twists or moves.

- Step 3** With the chassis positioned so the front is closest to the rack, insert the front of the chassis into the rack between the brackets, then slowly lower the chassis until it rests on the two bracket ledges. (See Figure 5.)

Figure 5 Sliding the Chassis into the Rack (Shown with Card Cage Assembly and Blower Installed)



- Step 4** Slide the chassis back into the rack along the ledges until the ears meet the front mounting posts on both sides of the rack. (See Figure 5.)

- Step 5** Secure each ear to the rack-mounting post with two 10-32 x 5/8-inch, Phillips pan-head screws.


This completes the procedure for moving the chassis into the rack.

Installing the Cable-Management Bracket

Once you have rack-mounted the new chassis, follow these steps to install the cable-management bracket:

- Step 1** At the interface processor end of the router, place the bracket above the card cage opening and align the holes in the bracket with the holes in the chassis.
- Step 2** Insert the screws through the bracket and into the chassis. (See Figure 6.)

Figure 6 cable-Management Bracket



- Step 3** When both screws are inserted, use a flat-blade screwdriver to tighten them.
- Step 4** When installing the network interface cables, route the cables to the cable-management bracket, as shown in Figure 6. If you are using very thin cables that slip through the bracket openings, insert cable ties through the holes in the bracket and wrap them around the cables to secure them.

It might be necessary to bundle longer cables to avoid tangling them. Do this at the cable-management bracket or at the rack, but leave enough room to be able to remove processor modules and change cables as required. Also, do not block the power supply air vents with cables.

This completes the procedure for installing the cable-management bracket.

Proceed to the next section for the procedure for removing processor modules.

Moving Processor Modules from the Old Chassis to the New Chassis

At the interface processor end of the chassis, slots contain the processor modules. (See Figure 1.) The RSP2 occupies RSP slot 6 or 7. The remaining eleven slots, which are numbered 0 through 5 (CyBus 0), beginning at the far left, and 8 through 12 (CyBus 1), support any combination of interface processors.

The processor modules are all keyed with guides on the backplane to prevent them from being fully inserted in the wrong slot. Empty interface processor slots contain an interface processor filler (an empty carrier) to help keep dust out of the chassis, provide EMI shielding, and maintain proper air flow through the chassis interior.

Processor modules slide into the processor slots and connect directly to the backplane. The spring-loaded ejector levers (see Figure 7) help to ensure that the bus connector on the back of the processor module is fully seated in the backplane or fully dislodged from it. Captive installation screws at both ends of each processor module faceplate prevent the processor from pulling away from the backplane and support the EMI integrity of the system. Failure to use the ejector levers and captive installation screws could result in a partial backplane connection, which can hang the system.

To retain your existing configuration, move interface processors to the same slot positions in the new chassis. The lithium battery backup on the RSP2 retains the system configuration in nonvolatile random-access memory (NVRAM). Therefore, if you install interface processors in the same slot positions in the new chassis that they occupied in the old chassis, the system and the individual interfaces should come up in their previous configuration. If you install interface processors in different slots in the new chassis, the system will recognize the interfaces, but will leave them in a shutdown state until you reconfigure and enable them.

Note We recommend that you use the slot and port configuration worksheet in Table 1 before you remove interface processors from the old chassis. (Also refer to Figure 10.) This will ensure that you install them in the correct slots in the new chassis based on the configuration stored in NVRAM on the RSP2.

Although interface processors support OIR, you must wait at least 15 seconds after inserting an interface processor before inserting the next one. To help avoid errors with the installation, leave the power off until you have moved all components into the new chassis and have verified that all of them are installed properly.


Move the interface processors first, one at a time, then move the RSP2 last. Before you remove an interface processor from the existing chassis, remove the interface processor filler from the corresponding slot in the new chassis. Then immediately install the interface processor in the new chassis and secure it in the slot before removing the next interface processor filler or module. If you leave the interface cables attached to the interface processors, route the cables through the cable-management brackets immediately after you secure the interface processor in the slot to help keep the other slots clear during the installation.

If there is sufficient slack in the interface cables, *and* if you can easily move the processor modules between the chassis without straining the cables, leave the interface cables connected. If you must disconnect the cables, label each cable with its slot and port number before you disconnect it. *Do not* reconnect the interface cables until you have installed all of the components in the new chassis (it is easier to install interface processors when the slots are not impeded by cables that drop from other slots). Use the optional cable-management brackets to keep the interface cables untangled and away from other interface processor slots and ports.



Caution You must turn OFF the system power before removing or installing the RSP2, which is a required system component. Removing the RSP2 while the system is operating will cause the system to shut down or crash and might damage or destroy memory files.

Figure 7 Ejector Levers and Captive Installation Screws



Follow these steps to move the processor modules to the new chassis:

- Step 1** Before moving any processor modules, ensure that you have met the following prerequisites (refer to the section “Prerequisites” on page 3 for details):
- On both chassis, ensure that the power is turned OFF and the power cable is disconnected from the AC power receptacle or the DC terminal block.
 - To prevent ESD damage, wear a grounding strap or other ESD-prevention device and attach the equipment end to the chassis ground screw on the interface processor end of the chassis. (See Figure 1.)
 - If you will leave the interface cables connected to the processor modules, ensure that there is sufficient slack to avoid straining the cables when moving the processor module between chassis. Otherwise, label each cable with its slot and port number position. (This will help avoid mixing up cables when you reconnect them.)
 - Optional: Install the cable-management brackets on the new chassis before moving the components. Either move the brackets from the old chassis or install a new set.
- Step 2** Note the slot location of the interface processor you are going to move. Before removing the interface processor, remove the interface processor filler from the corresponding slot in the new chassis. When installing interface processors in the new chassis, place them in the same slot position that they occupied in the old chassis; this will retain your existing configuration and will help avoid confusion when reconnecting cables and checking the installation.
- Step 3** If necessary, disconnect any interface cables that are connected to the processor module.
- Step 4** Use a screwdriver to loosen both of the captive installation screws on the processor module. (See Figure 7a.)
- Step 5** Place your thumbs on the end of each ejector and simultaneously pull both ejectors outward, away from the carrier handle (in the opposite direction from that show in Figure 7c) to release the processor module from the backplane.




Caution You must install the RSP2 in one of the slots labeled *RSP* (slot 6 or 7). We recommend that you place the RSP2 in the same slot in the new chassis that it occupied in the old one. You can install interface processors in any of the interface processor slots (the lowest slots), but we recommend that you install them in the same slot positions that they occupied in the old chassis. The slots are keyed for correct installation. Forcing a processor module into the wrong slot can damage the backplane and board connectors.

- Step 6** Grasp the processor module handle with one hand and pull the processor module straight out of the slot, keeping your other hand under the carrier to guide it. (See Figure 8.) Keep the carrier at a 90-degree orientation to the backplane. Avoid touching the board or any connector pins.
- Step 7** Place the processor module in the same slot position in the new chassis and align the notches along the edge of the carrier with the grooves in the slot. (See Figure 7a.)
- Step 8** While keeping the carrier at a 90-degree orientation to the backplane, carefully slide the carrier into the slot until the back of the faceplate makes contact with the ejector levers, then *stop*. (See Figure 7b.)

Do not use unnecessary force when installing processor modules. Always guide the carrier into the slot only until the carrier faceplate makes contact with the ejector levers; then use the ejector levers to complete the insertion.

- Step 9** Using the thumb and forefinger of each hand to pinch each ejector, simultaneously push both ejectors inward (toward the carrier handle) until they snap into place and are at a full 90-degree orientation to the faceplate. (See Figure 7c.) The carrier ears (the ends of the faceplate) should be flush against the chassis.
- Step 10** Use a screwdriver to tighten the two captive screws to prevent the processor module from becoming partially dislodged from the backplane and to ensure proper EMI shielding.
- Step 11** Repeat Steps 2 through 10 for the remaining interface processors.

Figure 8 Handling a Processor Module



Note Leave the interface processor filler installed in any unfilled interface processor slots.

This completes the processor module removal and replacement procedure. If you now need to install the new chassis in an equipment rack, proceed to the section “Installing the New Chassis in the Rack” on page 10. Otherwise, proceed to the next section to check the installation.

Checking the Installation

To complete the replacement procedure, perform the following steps to verify that the system is functioning properly. These steps will also help you verify that all the processor modules you moved are returned to their previous state. For additional first-time startup troubleshooting procedures, refer to the *Cisco 7513 Hardware Installation and Maintenance* publications.


Because the lithium battery backup on the RSP2 retains the system configuration in NVRAM, the system and the individual interfaces should come up in their previous configuration, provided that you installed the interface processors in the same slots they occupied in the old chassis.

If, however, you installed interface processors in different slot positions in the new chassis, the system will recognize the interfaces, but will leave them in a down state until you reconfigure and enable them.

If you need technical assistance, refer to the section “Cisco Information Online” at the end of this document.

- Step 1** Ensure that the system power switch is in the off position, then reconnect the power cable to the AC receptacle or DC terminal block, as required. For the AC-input power supply, snap the cable retention clip up around the plug to secure the cable. For the DC-input power supply, reattach a new nylon cable tie to support the weight of the cable.
- Step 2** Connect all interface cables to the appropriate interface processor ports. Ensure that all cables are fully seated in the ports and that all strain relief systems are engaged.
- Step 3** Ensure that you have either a console terminal connected to the system console port or a port available for a Telnet session to the router.
- Step 4** Turn ON the system power. On the power supplies, the (AC or DC) OK LED should go on and stay on. (See Figure 9.)

Figure 9 Power Supply LEDs (AC-Input Power Supply Faceplate Shown)



If the system does not go on, do the following. If it goes on, proceed to the next step.

- First, check the source power. Ensure that the power switch is completely in the on (I) position and that the power (input) cord is properly connected at both ends.
- Check the fan OK LED. When on, this LED indicates the blower is operating. If the (AC or DC) OK LED is off and the blower is not operating, there is most likely a problem with the (AC or DC) input power or with one of the internal DC lines. If so, there are no installation adjustments that you should make; contact a service representative for further instructions.

Step 5 Verify that the normal LED on the RSP2 goes on and stays on, which indicates that the system software booted successfully. If the LED goes on, proceed to the next step. If it does *not* go on, do the following:

- Check the ejector levers and captive installation screws on the processor modules. If any appear loose, use the ejector levers to reseal the module, then tighten the captive installation screws to secure it. Toggle the power off and back on again.
- If the RSP2 normal LED still remains off, note whether the CPU halt LED goes on, and contact a service representative.

Step 6 When the system boot is complete, the RSP2 begins to initialize the interface processors. During this initialization, the LEDs on each interface processor behave differently (most flash on and off). The enabled LED on each interface processor goes on when initialization has been completed.

- If the enabled LED on all interface processors goes on, the system has booted successfully and is now functional.
- If the RSP2 LEDs previously indicated a successful system boot, but none of the enabled LEDs on interface processors go on, suspect that one of the interface processors has shifted out of its backplane connector and hung the bus. Turn OFF the power, then use the ejector levers to release each interface processor and reseal them in their slots. (Refer to the section “Moving Processor Modules from the Old Chassis to the New Chassis” on page 13 for removal and insertion steps.) Tighten all captive installation screws; then return to Step 1.

Step 7 If the enabled LED on a single interface processor remains off, suspect that the interface processor has shifted out of its slot. Use the ejector levers to release the interface processor and reseal it in the backplane. (Refer to the section “Moving Processor Modules from the Old Chassis to the New Chassis” on page 13, for removal and insertion steps.) Tighten both captive installation screws; then return to Step 1.

Step 8 If an enabled LED still fails to go on after performing these steps, suspect that the specific interface processor has failed. Contact a service representative.

Step 9 Verify that the console terminal displays a script and system banner similar to the following:

```
GS Software (RSP-K), Version 10.3(571), SOFTWARE
Copyright (c) 1986-1995 by cisco Systems, Inc.
Compiled Wed 10-May-95 14:46 by mpo
```

```
System Bootstrap, Version 4.6(1) [fc2], SOFTWARE
```

Step 10 After the system initializes, use the various **show** commands to display the status of the system and individual interfaces, and ensure that they are operating according to their previous configuration. (For descriptions and examples of these commands, refer to the following section, “Verifying the Installation Using show Command Descriptions and Examples.”)

When the system starts up and operates successfully, the replacement procedure is complete, and you can resume normal operation.

If the system still fails to start up or operate properly, or if you isolate the cause of the problem to a failed component, contact a service representative for further assistance.

Note After you verify a successful installation, gather the old chassis and any remaining spares and parts. If the old chassis is still mounted in a rack, follow the steps in the section “Removing the Existing Chassis from the Rack” on page 9 to remove it. Place spare interface processors or interface processor fillers in the chassis slots, and move the chassis to the appropriate location for storage or shipment.

Verifying the Installation Using show Command Descriptions and Examples

This section describes the various **show** commands that you can use to display system status and configuration. If you installed the interface processors in the same slot locations that they occupied in the old chassis, the interfaces should retain the same configuration. If you installed the interface processors in different slot locations, the system will recognize the interfaces, but you will have to use the **configure** command to reconfigure and enable them.

You can check the version of the default ROM image either by removing the board and checking the ROM labels or by configuring the interface or system software to boot from ROM, restarting the system, and using these same commands to check the running version.

Use the **show version** command to display the current system software version, and use the **show controllers exbus** command to display the microcode version of the SP and each interface processor. In the following example of the **show version** command, the system software is Release 10.3(571)).

```
Router> show version

GS Software (RSP-K), Version 10.3(571), SOFTWARE
Copyright (c) 1986-1995 by cisco Systems, Inc.
Compiled Wed 10-May-95 14:46 by mpo

System Bootstrap, Version 4.6(1) [fc2], SOFTWARE

Current date and time is Sat 1-22-1994 21:38:35
Boot date and time is Tue 12-28-1993 15:32:28
Router uptime is 3 weeks, 4 days, 6 hours, 7 minutes
System restarted by reload
System image file is "gs7-k.103-1", booted via tftp from 1.1.1.12

(example text omitted
X.25 software, Version 2.0, NET2 and BFE compliant.
Bridging software.
1 EIP controller (6 Ethernet).
1 TRIP controller (4 Token Ring).
6 Ethernet/IEEE 802.3 interfaces.
4 Token Ring/IEEE 802.5 interfaces.
(remainder of example text omitted)
```

Following is an example of the **show controller cbus** command display. (In this example, ROM Version 1.0 is assumed because you cannot determine the ROM version with screen displays unless it is the running version.)

```
Router# show controllers cbus

(text omitted from example)
FSIP 1, hardware version 1.0, microcode version 1.0
Interface 8 - Serial1/0, electrical interface is V.35 DTE
(text omitted from example)
Interface 9 - Serial1/1, electrical interface is V.35 DTE
(remainder of displayed text omitted from example)
```

The command **show interfaces serial slot/port** displays statistics for the specific serial interface you specify by its slot/port address. If you use this command without the *type* and *slot/port* arguments, the system will display statistics for all interfaces in the system.

```
Router> show int hssi 1/0

Hssi 1/0 is up, line protocol is up
Hardware is cxBus HIP
Internet address is 1.1.1.9, subnet mask is 255.255.255.0
(display text omitted)
```

The command **show configuration** displays the contents of the system configuration file stored in NVRAM.


```
Router# show config

Using 1652 out of 130048 bytes
version 10.3(571)
!
hostname Router
!
enable-password guessagain
!
microcode TRIP flash tripl-0
microcode reload
!
interface hssi1/0
ip address 1.1.1.67
ip route-cache cbus
no keepalive
!
interface serial2/1
ip address 1.1.1.12
(display text omitted)
```

The command **show protocols** displays the global (system-wide) and interface-specific status of any configured Level 3 protocol.

```
Router> show protocols

Global values:
Internet Protocol routing is enabled
Hssi1/0 is up, line protocol is up
(display text omitted)
```

Figure 10 Slot Numbering (Use with Table 1)**Table 1 Port and Slot Configuration Worksheet (Refer to Figure 10)**

Port	Slot 0	Slot 1	Slot 2	Slot 3	Slot 4	Slot 5 ¹	Slot 8	Slot 9	Slot 10	Slot 11	Slot 12
1											
2											
3											
4											
5											
6											
7											
8											
Router Name				Location				Serial Number			

1. Slots 6 and 7 are reserved for the RSP2.

Cisco Information Online

Cisco Information Online (CIO) is Cisco Systems' primary, real-time support channel. Maintenance customers and partners can self-register on CIO to obtain additional content and services.

Available 24 hours a day, 7 days a week, CIO provides a wealth of standard and value-added services to Cisco's customers and business partners. CIO services include product information, software updates, release notes, technical tips, the Bug Navigator, configuration notes, brochures, descriptions of service offerings, and download access to public and authorized files.

CIO serves a wide variety of users through two interfaces that are updated and enhanced simultaneously—a character-based version and a multimedia version that resides on the World Wide Web (WWW). The character-based CIO (called "CIO Classic") supports Zmodem, Kermit, Xmodem, FTP, Internet e-mail, and fax download options, and is excellent for quick access to information over lower bandwidths. The WWW version of CIO provides richly formatted documents with photographs, figures, graphics, and video, as well as hyperlinks to related information.

You can access CIO in the following ways:

- WWW: <http://www.cisco.com>
- Telnet: [cio.cisco.com](telnet://cio.cisco.com)
- Modem: From North America, 408 526-8070; from Europe, 33 1 64 46 40 82. Use the following terminal settings: VT100 emulation; data bits: 8; parity: none; stop bits: 1; and baud rates up to 14.4 kbps.

For a copy of CIO's Frequently Asked Questions (FAQ), contact cio-help@cisco.com. For additional information, contact cio-team@cisco.com.

Note If you are a network administrator and need personal technical assistance with a Cisco product that is under warranty or covered by a maintenance contract, contact Cisco's Technical Assistance Center (TAC) at 800 553-2447, 408 526-7209, or tac@cisco.com. To obtain general information about Cisco Systems, Cisco products, or upgrades, contact 800 553-6387, 408 526-7208, or cs-rep@cisco.com.

This document is to be used in conjunction with the *Cisco 7513 Hardware Installation and Maintenance* publication. (1897ch13.fm)

Access Without Compromise, Catalyst, CD-PAC, CiscoFusion, Cisco IOS, CiscoView, CiscoWorks, HyperSwitch, LAN²LAN, LAN²LAN Enterprise, LAN²LAN Remote Office, LAN²PC, LightStream, Newport Systems Solutions, PC²LAN/X.25, Point and Click Internetworking, SMARTnet, SynchroniCD, *Packet*, UniverCD, WNIC, Workgroup Director, Workgroup Stack, and XCI are trademarks; Access by Cisco and Bringing the power of internetworking to everyone are service marks; and Cisco, Cisco Systems, the Cisco logo, EtherSwitch, and Kalpana are registered trademarks of Cisco Systems, Inc. All other trademarks, service marks, registered trademarks, or registered service marks mentioned in this document are the property of their respective owners.

Copyright © 1995, Cisco Systems, Inc.
All rights reserved. Printed in USA
956R