

Preparing to Install CiscoWorks

This chapter describes how to prepare for installing and configuring CiscoWorks, and provides worksheets to help you gather the necessary information.

Before you install the CiscoWorks network management software, confirm that your computer system meets the related hardware and software-version requirements. In addition, you should note any special requirements about how you want CiscoWorks installed. For example, CiscoWorks prompts you during installation to supply information such as where you want CiscoWorks installed and whether you are performing a new installation or an upgrade.



Timesaver If you do not have any special requirements, you can just press the Return key during the installation to accept a default selection.

To gather all the information you need to install CiscoWorks, first complete the CiscoWorks Installation Worksheet later in this section. You can then refer to the worksheet, if necessary, as you proceed with the installation.

Process Overview

This section provides an overview of the recommended tasks to perform before installing and configuring CiscoWorks.

Follow these steps to prepare for installing and configuring CiscoWorks for the first time or for upgrading from an earlier version of CiscoWorks. After you complete the following steps, you are ready to install and configure CiscoWorks on your system.

- 1 Verify that your workstation meets the minimum hardware and software requirements for CiscoWorks. (See the section “Verifying Your System Requirements.”)
- 2 Gather information required for installation and configuration by filling in the Installation and Configuration Worksheets. (See the section “Gathering Information for Installation and Configuration.”)
- 3 Become a superuser on your system. (See the section “Becoming a Superuser.”)
- 4 If you are upgrading from an earlier version of CiscoWorks, first make a back-up copy of your existing version of CiscoWorks.
- 5 Upgrade your SunOS to Version 4.1.2 or later. (See the section “Upgrading to CiscoWorks 2.1.”) Note that CiscoWorks does not run on Solaris 2.x.

- 6 Install HP OpenView on your Sun workstation. For instructions on installing HP OpenView, refer to the *HP OpenView Installation Guide*.
Verify that HP OpenView is installed on your system by starting the HP OpenView Console with the sample database file created during installation. Test the HP OpenView installation by starting a request to an agent on your local machine. Using the HP OpenView menu option **Monitor>MIB Values>Browse MIB:SNMP**, you can ensure that the agent is responding.
- 7 To verify the installation of all HP OpenView products on your system, enter the **ovverify** command at the UNIX prompt.
- 8 Set up the Trivial File Transfer Protocol (TFTP). (See the section "Setting Up TFTP.")

Verifying Your System Requirements

Before you install CiscoWorks on your system, make sure that your system meets the hardware and software requirements described in the following sections.

Hardware Requirements

CiscoWorks requires the following hardware:

- Any one of the following workstations: Sun SPARCstations 1, 1+, 2, or 10; SLC; IPC 330, 370; Sun-4/xx series; Sun SPARC Classic with SunOS Version 4.1.3c.
- Hard disk space requirements as described in Table 2-1. CiscoWorks software requires a single disk partition on your system, with a minimum of 500 megabytes (MB) of disk space (1,000 MB recommended).
- The HP OpenView software exists in the */usr/OV* directory, unless you installed it in a different directory. Hewlett Packard recommends 10 to 15 MB of space for the initial database directory to allow enough space for the growth of HP OpenView log files. If the log files require more hard disk space, you can change the location of the database directory. For detailed information on the hard disk space requirements for HP OpenView and on changing the location of the database directory, refer to the *HP OpenView Windows User's Guide*.
- Random-access memory (RAM) requirements as described in Table 2-1.
- 64 MB of RAM. Additional swap space is required for managing large numbers of devices. For managing more than 75 to 100 devices, Cisco recommends at least 128 MB of swap space.
- Color monitor.
- CD-ROM drive that is local to the workstation or available remotely through the network.
- PostScript-compatible printer (in order to print snapshot images).

Table 2-1 General System Requirements for CiscoWorks 2.1(x)

Operating System	Free Hard Disk Space	RAM	Swap Space	Free Root Partition Needed for CiscoWorks
Solaris 1.x (SunOS 4.1.2 or 4.1.3)	500 MB (minimum) 1,000 MB (recommended)	64 MB	110 MB (minimum) 128 MB (recommended)	5 MB

The memory and swap space requirements of CiscoWorks ultimately depend on such factors as which applications you want to run, the number of applications you want to run concurrently, and the number of network devices that you want to manage with CiscoWorks. As a result, you may need to increase the swap space beyond the general minimum requirements, depending on your particular network management needs.

Software Requirements for Sun Workstations

On Sun workstations, CiscoWorks requires the following software:

- SunOS Version 4.1.2 or later
- OpenWindows Version 3.3 or later
- HP OpenView 3.3

Several CiscoWorks applications have specific Cisco Systems software requirements. For more information, refer to the *CiscoWorks User Guide*. The Configuration Management application, for example, requires Cisco Systems Software Release 8.2 or later.

System Sampler of Five Devices Managed by CiscoWorks

The following sample configuration represents the system requirements used by a network manager who ran six common CiscoWorks applications on HP OpenView in order to manage five network devices. Table 2-2 lists the swap space requirements of this sample network:

Table 2-2 Swap Space Used to Manage Five Network Devices

CiscoWorks Network Management Components	Swap Space Usage
CiscoWorks daemons (collective processes that perform the specific functions of CiscoWorks)	15,704 KB
Sybase database	2682 KB
HP OpenView	9000 KB
Sun operating system	30,720 KB
Configuration Snap-In Manager	26,969 KB
Process Manager	3588 KB
Configuration Management	7893 KB
Device Management	5082 KB
Global Command Manager	7121 KB
Sync w/Sybase	7168 KB
Total amount of swap space usage	10,8975 KB or 106.42 megabytes (MB)

The collective swap space used by the CiscoWorks daemons (15704 KB) in Table 2-2 reflects what is used by the four significant CiscoWorks daemons as they manage five devices. As more devices are added, the swap space requirements increase as shown in Table 2-3.

Table 2-3 Swap Space Used by Daemons to Manage Five Network Devices

CiscoWorks Daemons that Use Significant Swap Space	Swap Space Usage	Swap Space Required for Each Additional Device
nmlogd	676 KB	No adjustments
nmpolld	8192 KB	500 KB
nmeventd	2536 KB	No adjustments
Total	11404 KB or 11.1 megabytes (MB)	500 KB of swap space for each new device managed by CiscoWorks

Depending on the router you are using, the Software Manager application requires a specific Cisco Systems Software Release according to the following table (Table 2-4):

Table 2-4 Router and Software Requirements for Use with Device Software Manager

Cisco Router Type	Router System Software Requirement
Cisco 3000	Software Release 9.1(7.5) or later, or 9.1(8) or later
Cisco AGS+	Software Release 9.1(7.5) or later, or 9.1(8) or later
Cisco 4000	Software Release 9.14(3.4) or later, or 9.14(4) or later

Cisco Router Type	Router System Software Requirement
Cisco 7000	Software Release 9.17(5.2) or later, or 9.17(6) or later
All Cisco routers (collection of Cisco 3000, Cisco 4000, Cisco 7000, or AGS+ routers)	Software Release 9.21(0.26) or later; 9.21(1) or later; or 9.1(8) or later
Cisco 7000 routers on which you want to perform microcode upgrades	Software Release 9.17(5.2) or later; 9.17(6) or later; 9.21(0.32) or later; or 9.21(1) or later

Gathering Information for Installation and Configuration

Before you install and configure CiscoWorks, use the CiscoWorks Installation Worksheet and Configuration Worksheet to identify installation requirements and gather the information required for running the installation and configuration scripts.

When properly filled out, the CiscoWorks Installation Worksheet provides the information you must enter when running the installation scripts, before you physically install CiscoWorks. After you install CiscoWorks, you are ready to configure it. The CiscoWorks Configuration Worksheet enables you to gather the information you need to run the script that configures CiscoWorks.

Complete both worksheets and refer to them when installing and configuring your CiscoWorks software.

Filling in the CiscoWorks Installation Worksheet

The CiscoWorks Installation Worksheet and descriptions follow.

CiscoWorks Installation Worksheet

INSTALLATION WORKSHEET FOR SUN WORKSTATIONS			
SunOS 4.1.2. or later?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
A window manager such as Motif?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
HP OpenView 3.3?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
1000 MB of free hard disk space for CiscoWorks on a single disk partition?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
64 MB of RAM?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
110 MB of swap space?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
Set up TFTP to transfer configuration files?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
INSTALLING CiscoWorks			
Location of CD-ROM drive?	<input type="checkbox"/> local	<input type="checkbox"/> remote	
If the CD-ROM drive is remote, do you have superuser access to the remote system?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
Name of the remote system? _____			
For the remote installation does the /.rhosts file contain the local host name of your system and list your username as root?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
Device name of the CD-ROM drive?	<input type="checkbox"/> sr0	<input type="checkbox"/> sr1	<input type="checkbox"/> sr2
	<input type="checkbox"/> other _____		
Type of installation?	<input type="checkbox"/> new	<input type="checkbox"/> upgrade	
Complete path name of the directory where CiscoWorks will be installed?	<input type="checkbox"/> /usr/nms	<input type="checkbox"/> other _____	
Disk partition for installing Sybase?	<input type="checkbox"/> \$NMSROOT	<input type="checkbox"/> other _____	
Name of the kernel configuration file in the /usr/share/sys/ARCH/conf directory?	<input type="checkbox"/> Generic	<input type="checkbox"/> other _____	
TACACS INFORMATION			
Installing a TACACS server?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
Start TACACS daemon during system reboot?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
TACACS username? _____			
Username password? _____			
Using extended TACACS mode?	<input type="checkbox"/> yes	<input type="checkbox"/> no	
Extended TACACS mode password? _____			
ADDITIONAL UPGRADE INFORMATION			
Complete path name of the directory for the existing version of CiscoWorks?	<input type="checkbox"/> /usr/nms	<input type="checkbox"/> other _____	
Sybase SA password? _____			
Does the system have at least 45 MB of disk space for the upgrade and 10 MB for saving the existing database?	<input type="checkbox"/> yes	<input type="checkbox"/> no	

Installation Worksheet Items

This section explains each question on the Installation Worksheet. This information is required for the installation of CiscoWorks. To obtain and verify system information for some items in the worksheet, you will need to be logged in as a superuser. For information on how to log in as a superuser, refer to the section “Becoming a Superuser.”

Sun OS Requirements

Your workstation must be running SunOS Version 4.1.2 or 4.1.3 before you can install CiscoWorks. To determine what version of SunOS you are using, enter the following command at the UNIX prompt:

```
hostname% uname -r
```

The SunOS version number displays on your monitor:

```
4.1.2
```

On your worksheet, indicate whether your system meets this requirement.

Windowing System

You must install HP OpenView Windows Version 3.3 on your workstation.

On your worksheet, indicate whether your system meets this requirement. If you check no, you need to install HP OpenView Windows Version 3.3.

HP OpenView Installation

You must install HP OpenView 3.3 on your workstation before you can install CiscoWorks. To find out whether HP OpenView is already installed on your system, enter the following command:

```
hostname% /usr/ov/bin/ovlicense
```

If HP OpenView is properly installed, you should see output that verifies that the OpenView license is valid. On your worksheet, indicate whether your system meets this requirement. If you check “no,” you need to upgrade to HP OpenView 3.3.

Hard Disk Space

CiscoWorks requires 500 MB of disk space (1,000 MB recommended) in a single disk partition on your system. If the disk partitions on your system are full, with inadequate disk space available for CiscoWorks, create a disk partition, a file system, or both for CiscoWorks software.

On your worksheet, indicate whether your system meets this requirement. If you check “no,” you need to increase the disk partition. If you are not sure whether your system meets this requirement, refer to the next section, “Calculating Disk Space Requirements.”

Calculating Disk Space Requirements

Although the required disk space is displayed during installation, Cisco Systems recommends that you calculate the space ahead of time to ensure its availability. You need to allocate 45 MB of disk space for the CiscoWorks installation.

If you are upgrading from an earlier version of CiscoWorks, add the amount of disk space used in the current *\$SYBASE/data* directory, roughly 10 MB, to the 45 MB disk space requirement.

To estimate the disk space required for an upgrade, perform the following steps:

Step 1 Enter the following command:

```
hostname% du -s $SYBASE/data
```

This command reports the total number of kilobytes used by the `$SYBASE/data` directory.

Step 2 Divide the number of kilobytes in the `$SYBASE/data` directory by 1000.

This calculation gives you the approximate number of megabytes used in the `$SYBASE/data` directory.

Step 3 Add 45 MB to the number of megabytes calculated in step 2.

This is the disk space you will need to perform your upgrade.

Remember, if you are upgrading from a previous version of CiscoWorks, the process requires at least 10 MB of free space in the database.

To find out how much disk space is available on your system, enter the following command:

```
hostname% df
```

The amount of disk space available in each file system is displayed. Select a file system that has sufficient disk space available for installing CiscoWorks. For detailed information on how to manage disk partitions and file systems, refer to the *Workstation and Network Administration* publication.

The following overview summarizes the steps involved in creating a file system. For more information, refer to the *Workstation and Network Administration* publication or the manual pages on `mkfs`, `fsck`, `mkdir`, `fstab`, and `mount`. If you are unfamiliar with repartitioning disks or creating file systems, contact a knowledgeable system administrator.

Step 1 Create an empty file system on the disk partition you plan to use.

Step 2 Verify the integrity of the empty file system.

Step 3 Create a mount point directory.

Step 4 Configure the file system table and edit the `/etc/fstab` file.

Step 5 Mount the new file system.

RAM

CiscoWorks requires a minimum of 64 MB of RAM. To find out how much RAM is available on your system, make sure you are logged in as a superuser. Then enter the following command at the UNIX prompt:

```
hostname# dmesg | grep avail
```

The entry “avail mem” indicates the amount of RAM memory available on your system.

On your worksheet, indicate whether your system has at least 64 MB of RAM. If you check “No,” you need to install more memory.

Swap Space

CiscoWorks requires a minimum of 110 MB (128 MB recommended) of swap space on your system. To find out how much swap space is available on your system, make sure you are logged in as a superuser. (Refer to “*Becoming a Superuser.*”) Then use the following command at the UNIX prompt:

```
hostname# pstat -s
```

The output that displays on your monitor indicates the amount of swap space available on your system.

On your worksheet, indicate whether your system has at least 110 MB. If you check “No,” you need to add more swap space. If the swap space on your system is less than 110 MB, expand the swap space by following the instructions in the *Workstation & Network Administration* publication.

Configuring TFTP for Device Configuration Management

After CiscoWorks is installed and configured, you can use several applications (Configuration Management, Configuration Management batch program, AutoInstall Manager, Software Library Manager, Device Software Manager, Configuration Snap-In Manager, and Sync w/Sybase) with the Trivial File Transfer Protocol (TFTP). With TFTP and CiscoWorks, you can transfer configuration files and software images between your system and other devices on your network that use the Simple Network Management Protocol (SNMP).

In order for TFTP to operate, you must follow the instructions in the section “*Setting Up TFTP.*” You can perform this task either before or after CiscoWorks installation and configuration.

On your worksheet, indicate whether you want TFTP enabled on your system.

CD-ROM Drive Location

You can install CiscoWorks from a local or remote CD-ROM drive.

On your worksheet, indicate which method you will use.

Remote Installation

If you are planning to install CiscoWorks from a CD-ROM drive attached to a remote system, find out whether you have a login account as a superuser (in other words, *root*) on that system. If you do not have superuser access to the remote system, contact the system administrator of the remote system to obtain a login account with superuser access to that system.

If you are installing CiscoWorks from a remote CD-ROM drive, obtain the complete host name of the remote system and make sure that this host name is listed in the */etc/hosts* file on your system.

On your worksheet indicate whether you have superuser access, and enter the host name of the remote system.

Checking the *.rhosts* File

The *.rhosts* file enables users to log into another user account on a remote system. If you plan to install CiscoWorks from a remote CD-ROM drive, the *.rhosts* file on that system must contain the host name of your local system and your username specified as a superuser. To verify the local host name and that your username is specified as superuser, access the *.rhosts* file by using a text editor such as vi or textedit.

For more information on the *.rhosts* file, refer to the *SunOS Network Environment* publication.

On your worksheet, indicate whether your host name is in the *.rhosts* file and your username is specified as a superuser.

Device Name

The installation script requires you to specify the device name of the CD-ROM drive. You can either obtain the device name from your UNIX system administrator or display the contents of the */dev* directory on your system by following these steps:

Step 1 Change to the */dev* directory:

```
hostname% cd /dev
```

Step 2 Verify that you are in the */dev* directory by entering the following command:

```
hostname% pwd
```

The directory path displays.

Step 3 List the devices available to your system to find out whether you have a device name similar to *sr* by entering the following command. (CD-ROM drives usually have device names similar to *sr0*, *sr1*, *sr2*, and so on.)

```
hostname% ls | more
```

A list of available devices displays on your monitor.

Step 4 To display the remainder of the list of devices, press the space bar.

If you cannot identify an appropriate device name for your CD-ROM drive, contact your UNIX system administrator for help in obtaining device information.

Check the appropriate box on your worksheet and, if applicable, specify the name of the device.

Type of Installation

If you are installing CiscoWorks for the first time, check “new” on your worksheet.

Note Even if you are using an earlier version of CiscoWorks, such as version 2.0, you must install CiscoWorks 2.1 as a new installation because you upgrading the network management software (CiscoWorks) as well as the network management platform (HP OpenView).

If you are upgrading from an early version of CiscoWorks 2.1 to a later version of CiscoWorks 2.1, with both versions on a Sun workstation, check “upgrade.” If you are upgrading, you must fill out the “Additional Upgrade Information” section at the end of the worksheet.



Caution With CiscoWorks 2.0 or later, a user can only belong to one group; therefore when upgrading, only the existing one-user-to-one-group associations will be preserved. After upgrading, you need to redefine all other user/group associations.

Directory Path Name for CiscoWorks

You must specify the directory where you want the CiscoWorks software to be installed. If the directory does not already exist on your system, the installation script creates the directory and installs the software in that directory. The default directory path name is */usr/nms*.

On your worksheet, indicate where the CiscoWorks software will be installed. If applicable, specify the directory path name you plan to use.

Selecting a Disk Partition for Sybase and Transaction Log Installation

If you are performing a new installation only, the installation script allows you to specify the disk partition on which you want to install Sybase and the corresponding transaction log, or to accept the default *\$NMSROOT*. Depending on your needs, you can even share the Sybase installation across several disk partitions. In addition to choosing a location, you can specify the size of your database and transaction log.

Because the size of your particular database can vary, the installation program prompts you for how much space you want to allocate for Sybase and for the corresponding transaction log. For Sybase, specify a size that is at least 6 MB; or you can accept the default size of 50 MB. For the transaction log, specify a size that is at least 4 MB; or you can accept the default size of 10 MB.

After you specify a size and location for the disk partition, the installation script automatically checks to make sure you have the specified disk space before installing the database. If you do not have the disk space you requested, CiscoWorks automatically prompts you to select other partitions.

Sybase Modifications to the Kernel Configuration File

All workstations contain a kernel. In order for the Sybase Version 4.9.1 software to work on your system, you must modify the kernel. The kernel is built from a configuration file in either of the following directories:

```
/usr/share/ARCH/conf
/usr/sys/ARCH/conf
```

where *ARCH* can be *sun4c*, *sun4m*, or *sun4n*.

Most systems use a generic kernel that is stored in a configuration file called *GENERIC*. If the kernel was customized for your system, it might be stored in a customized configuration file with a different name. If you choose to allow the installation script to build the new kernel, it uses your current system configuration.

When you are logged in as superuser, you can also modify the kernel manually by following these steps:

Step 1 Back up your existing configuration file by entering the following command:

```
hostname# cp /vmlinix /vmlinix.bak
```

Step 2 Change directories by entering one of the following commands:

```
hostname# cd /usr/share/ARCH/conf
hostname# cd /usr/sys/ARCH/conf
```

Step 3 Copy the base kernel configuration file (usually called *GENERIC*) to *filename* by entering the following command, where *filename* is the name of the kernel configuration file:

```
hostname# cp GENERIC filename
```

Step 4 Add the following lines anywhere in the `/usr/sys/ARCH/conf/<filename>` file or `/usr/share/ARCH/conf/<filename>` file (if these lines already exist, you will need to modify them, not add them):

```
options "SHMSIZE=0x20000"
options "SEMMNS=640"
options "SHMMNI=256"
```

Step 5 Enter the following command:

```
hostname# config filename
```

This command executes the configuration process and builds a directory called `../filename`. You then return to the UNIX prompt.

Step 6 At the UNIX prompt, enter the following command:

```
hostname# cd ../filename
hostname# make
```

This command creates a file called `vmunix` or `vmunix_small`.

Step 7 Copy the `vmunix` or `vmunix_small` file, created in the previous step, by entering one of the following commands:

```
hostname# cp ./vmunix /vmunix
hostname# cp ./vmunix_small /vmunix
```

Step 8 Restart your system. The modified kernel is now loaded and ready for use with Sybase.

Step 9 For more information on modifying the kernel, refer to your *Sun Workstation and Network Administration* publication.

If you allow the installation script to modify the kernel configuration file, the script automatically saves the old kernel configuration file and names it as `vmunix.syb_inst`. You can remove this file or save it as a backup, as your needs determine.

On your worksheet, indicate the name of the kernel configuration file. If you want the installation script to modify the existing kernel, check `GENERIC`. If you want the installation script to modify a customized configuration file on your system, specify the name of this file.

TACACS Information

CiscoWorks provides support for Terminal Access Controller Access System (TACACS). TACACS is an authentication protocol that requires users to supply a username and password in order to access Cisco devices.

Setting Up a TACACS Server

When prompted by the installation script, you must indicate whether your workstation will be set up as a TACACS server. On your worksheet, indicate whether your system is to be set up as a TACACS server.

Start TACACS Daemon during System Reboot

If you set up your network system as a TACACS server, the TACACS daemon startup facility will be automatically added to the `/etc/rc.local` file. During installation, if you respond `Y[es]` to set up a TACACS server, you are then asked whether you want the TACACS daemon to start automatically.

when you restart the system. If you answer no, the TACACS daemon will still be added to your *etc/rc.local* or but will be commented out. On your worksheet, indicate whether you want this functionality.

TACACS Username

If you elect to set up a TACACS server, you need to supply a username when prompted by the installation script. The username you supply here is the one that is provided when a user attempts to remotely log in to manage Cisco devices.

Username Password

If you elect to set up a TACACS server, you need to supply a TACACS password. On your worksheet, indicate the password for the specified TACACS username.

Using Extended TACACS Mode

The TACACS extended account, named *\$enable\$*, is used to access routers that use the extended TACACS mode. For more information on the *\$enable\$* account, see the *CiscoWorks User Guide*. On your worksheet, indicate whether you want your system to run in extended TACACS mode.

Extended TACACS Mode Password

If you answered “Y” to accept an extended TACACS mode, you are then prompted to supply the password for the special TACACS *\$enable\$* account. On your worksheet indicate the password that should be used for the extended TACACS user account.

Additional Upgrade Information

This section explains items in the worksheet that are applicable only if you are upgrading from an early version of CiscoWorks 2.1 to the final version of CiscoWorks 2.1

Note If you are upgrading from an existing version of CiscoWorks (in which users may have belonged to more than one group), the installation script presents a message advising you that any existing user-to-multiple-group associations will be disconnected. If you proceed with the upgrade, you must use the Security Manager application to reconnect each user to one group only; then add the group to a domain. Any existing one-user-to-one-group associations will be preserved during the upgrade.

Complete Path Name for Existing CiscoWorks Directory

Specify the directory of your existing CiscoWorks software. The installation script installs the new CiscoWorks software in the directory you specify here.

On your worksheet, check */usr/nms* to accept the default, or specify a path name for another directory.

Sybase Password

During installation, the installation script accesses the existing Sybase database on your system. In order to access the existing Sybase database, the script prompts you to enter the Sybase password.

On your worksheet, specify the Sybase password (sa and nmsuper).

Disk Space for Saving the Existing Database

The CiscoWorks installation script installs a new version of Sybase, which requires 45 megabytes of disk space. The database should have 10 megabytes of free space before running the upgrade.

On your worksheet, indicate whether your system meets this requirement. If you check “No,” you need to add more disk space.



Caution Remember to back up your Sybase database prior to upgrading to ensure your data has been saved.

Filling in the CiscoWorks Configuration Worksheet

The CiscoWorks Configuration Worksheet and descriptions follow.

CiscoWorks Configuration Worksheet

CONFIGURATION WORKSHEET FOR SUN WORKSTATIONS		
Type of installation?	<input type="checkbox"/> new	<input type="checkbox"/> upgrade
Directory location where CiscoWorks is installed?	<input type="checkbox"/> /usr/nms	<input type="checkbox"/> other _____
Directory location where Sybase is installed?	<input type="checkbox"/> /use/nms	<input type="checkbox"/> other _____
CiscoWorks group name?	<input type="checkbox"/> CscWorks	<input type="checkbox"/> other _____
CiscoWorks group ID?	<input type="checkbox"/> 55	<input type="checkbox"/> other _____
Usernames of individuals with login accounts who will be added to the CiscoWorks group?	Username _____	
	Username _____	
	Username _____	
	Username _____	
CiscoWorks username?	<input type="checkbox"/> cscworks	<input type="checkbox"/> other _____
CiscoWorks user ID number?	<input type="checkbox"/> 100	<input type="checkbox"/> other _____
CiscoWorks login account name?	<input type="checkbox"/> CiscoWorks	<input type="checkbox"/> other _____
CiscoWorks home directory?	<input type="checkbox"/> /usr/nms	<input type="checkbox"/> other _____
Type of shell for CiscoWorks?	<input type="checkbox"/> /bin/csh	<input type="checkbox"/> other _____
CONFIGURING SYBASE		
Sybase user ID number?	<input type="checkbox"/> 101	<input type="checkbox"/> other _____
Sybase group ID?	<input type="checkbox"/> 55	<input type="checkbox"/> other _____
Sybase full name?	<input type="checkbox"/> Sybase	<input type="checkbox"/> other _____
Type of shell for Sybase?	<input type="checkbox"/> /bin/csh	<input type="checkbox"/> other _____
CONFIGURING LOG FILES AND FACILITIES		
Directory pathname for HP Openview?	<input type="checkbox"/> /usr/OV	<input type="checkbox"/> other _____
Log file for CiscoWorks messages?	<input type="checkbox"/> /var/log/nmslog	<input type="checkbox"/> other _____
Syslog facility for CiscoWorks messages?	<input type="checkbox"/> local7	<input type="checkbox"/> other _____
Erasing applications that use the facility?	<input type="checkbox"/> yes	<input type="checkbox"/> no
Enabling the CiscoWorks log purging utility?	<input type="checkbox"/> yes	<input type="checkbox"/> no
ADDITIONAL INFORMATION FOR AN UPGRADE CONFIGURATION		
Installing new MIB files and saving old MIB files?	<input type="checkbox"/> yes	<input type="checkbox"/> no
Replace the current CiscoWorks startup in /etc/rc file with the new version of CiscoWorks?	<input type="checkbox"/> yes	<input type="checkbox"/> no

Configuration Worksheet Items

This section explains each question on the Configuration Worksheet. This information is required for the configuration of CiscoWorks. For detailed information on the */etc/passwd* and */etc/group* files, usernames, user IDs, group names, and group IDs, refer to the publications for the operating system you are using.

Type of Installation

On your worksheet, indicate whether the CiscoWorks installation is a new installation or an upgrade. If you are performing an upgrade, you may want to complete the last section of the worksheet that requires additional information on configuring the upgrade.

Directory Where CiscoWorks Is Installed

On your worksheet, indicate */usr/nms* or another directory path.

Note The following information for groups and users is normally applied to the */etc/passwd* and */etc/group* files on the host system. If you are running Network Information Services (NIS) at your site, you must manually update these entries on your NIS server.

Directory Where Sybase Is Installed

On your worksheet, indicate */usr/nms* or another directory path to record where the Sybase database is installed.

CiscoWorks Group Name

In order for CiscoWorks users to access and use CiscoWorks, they must belong to a CiscoWorks group that is specified in the */etc/group* file on your system. The configuration script prompts you to supply the group name you want to use for CiscoWorks users. The default name for the group is *CscWorks*.

During CiscoWorks configuration, you can add new users directly to the *CscWorks* group. The configuration script presents you with an interactive screen display that allows you to add new users directly to the *CscWorks* group. As a result, you can add new users to the *CscWorks* group during the configuration process without editing the */etc/group* file. However, to add a new user after performing the CiscoWorks configuration, you need to edit the */etc/group* file.

If you are upgrading from a presales version of CiscoWorks 2.1, you can use the CiscoWorks group name that you used for the previous version of CiscoWorks.

On your worksheet, check “*CscWorks*” to accept the default, or specify a unique name for the CiscoWorks group.

CiscoWorks Group ID

The CiscoWorks group, which is created and added to the */etc/group* file by the configuration script, must be assigned a unique number. The configuration script proposes a default group ID number. If you specify a different group ID number for the CiscoWorks group, make sure that no other group specified in the */etc/group* file uses it.

On your worksheet, check “55” to accept the default, or specify a unique group ID number for CiscoWorks.

Usernames for CiscoWorks Group

In order to specify usernames while running the installation script and allow users to access and use CiscoWorks, the following prerequisites apply:

- A user must have a login account on the workstation.
- The login account information for each user must exist in the */etc/group* and the */etc/password* files on the system.

If you need to create user login accounts, refer to the instructions in *Sun System & Network Administration* publication.

On your worksheet, enter the usernames for users who have valid login accounts on your system and need to access CiscoWorks. If you are upgrading from a previous version of CiscoWorks, the configuration script displays the usernames of existing CiscoWorks users. You can either accept them and or add new usernames. To remove names, use a standard UNIX system administration utility.

CiscoWorks Username

In order for the CiscoWorks software to work on your system, you must specify a CiscoWorks login account and username when prompted by the configuration script. Cisco recommends that you use the default username *cscworks*. The configuration script adds the CiscoWorks login account and username to the */etc/passwd* file. In addition, the username is added to the CiscoWorks group in the */etc/group* file.

On your worksheet, indicate that you accept the default username or specify a unique name for the CiscoWorks login account.

CiscoWorks User ID Number

Users with valid login accounts and usernames on your system have unique user ID numbers that are specified in the */etc/passwd* file. The CiscoWorks login account, which is created and added to the */etc/passwd* file by the configuration script, requires a unique user ID number. The configuration script proposes a default user ID number (100). To specify a different user ID number for the CiscoWorks login account, make sure that no other user login account uses it.

On your worksheet, check *100* to accept the default number, or specify a unique user ID number for the CiscoWorks username.

CiscoWorks Login Account Name

The configuration script proposes a default full name (CiscoWorks).

On your worksheet, check *CiscoWorks* to accept the default name, or specify a different full name for the CiscoWorks login account name.

CiscoWorks Home Directory

The configuration script installs the CiscoWorks software in a directory on your system. The default directory is */usr/nms*.

On your worksheet, check */usr/nms* to accept the default name, or specify a different subdirectory for the Sybase software.

Type of Shell for CiscoWorks

As a user, you interact with the UNIX operating system by means of a shell. Two standard shells used on UNIX systems are the C shell and the Bourne shell. The C shell (*/bin/csh*) is the default shell you will use for Sybase-related tasks that are performed at the UNIX prompt.

On your worksheet, check */bin/csh* to accept the default name, or specify a different subdirectory for the Sybase software, and if applicable, specify a shell of your choice.

Sybase Username

The CiscoWorks software includes Sybase Version 4.9.1 software. In order for the Sybase software to work on your system, you must specify a Sybase login account and username. During database configuration, the script prompts you to supply the username for Sybase. Cisco recommends that you use the default username *sybase*. The script then adds the sybase login account and username to the */etc/passwd* file. In addition, the username is added to the CiscoWorks group in the */etc/group* file.

On your worksheet, check *sybase* to accept the default username, or specify a unique name for the Sybase login account.

Sybase User ID Number

Users with valid login accounts and usernames on your system have unique user ID numbers that are specified in the */etc/passwd* file. The Sybase login account, which is created and added to the */etc/passwd* file by the configuration script, must be assigned with a unique user ID number. The script proposes a default user ID number (101). If you specify a different user ID number for the sybase login account, make sure that no other user login account uses it.

On your worksheet, check *101* to accept the default user ID, or specify a unique user ID number for the Sybase username.

Sybase Group ID Number

The Sybase group, which is created and added to */etc/group* file by the *ncsconfigure* script, must be assigned a unique number. The configuration script proposes a default group ID number (55).

On your worksheet, check *55* to accept the default group ID number, or specify one that is not already in use by a group in the */etc/group* file.

Sybase Full Name

A full name must be specified for the Sybase login account.

On your worksheet, check *Sybase* to accept the default Sybase full name, or specify a different full name for the Sybase login account.

Type of Shell for Sybase

As a user, you will interact with the UNIX operating system by means of a shell. Two standard shells used on UNIX systems are the C shell and the Bourne shell. The C shell (*/bin/csh*) is the default shell you will use for Sybase-related tasks that are performed at the UNIX prompt.

On your worksheet, check */bin/csh* to accept the default shell, or specify a shell of your choice.

Directory Path Name for HP OpenView

The CiscoWorks software must identify the directory where HP OpenView software was installed on your system. Unless you installed the HP OpenView software in a different directory, the HP OpenView software is generally installed in the default directory */usr/OV*.

Verify the directory where the HP OpenView software is installed on your system. If it is installed in the */usr/OV* directory, check */usr/OV* on your worksheet. Otherwise, specify the directory where the HP OpenView software was installed.

Log File for CiscoWorks Messages (Sun Workstations)

The CiscoWorks Log Manager application uses a centralized log file, */var/log/nmslog*, which gets messages from the UNIX *syslogd* process. If you want these messages to be logged to a different file, you can specify a different filename.

On your worksheet, check */var/log/nmslog* to accept the default log file, or specify a different filename where the messages can be logged.

Syslog Facility for CiscoWorks Messages

The CiscoWorks Log Manager application uses a centralized log file that gets messages from the UNIX *syslogd* process. The default facility is *local7*.

If you want to log both CiscoWorks messages and Cisco device messages and view them through the Log Manager application, use the default facility *local7*. Cisco routers use the *local7* facility. If you specify a facility in the range of *local0* through *local6*, only CiscoWorks messages are logged.

Information about the facility you choose will be stored in the *\$NMSROOT/etc/nms.rc* file. At a later time, you can change the facility you use by modifying the *rc.local* file and either setting the *NMSSYSLOG* environment variable or editing the *nms.rc* file. For instructions on performing these tasks, refer to the *CiscoWorks User Guide*.

On your worksheet, check *local7* to accept the default facility, or specify a facility of your choice.

Erasing Applications That Use the Syslog Facility

The configuration script asks you whether it can erase any other applications that are using this facility. If you answer no, the CiscoWorks log utility might not be able to use the Syslog facility to do the following:

- Transfer or exchange information such as error messages.
- Receive extraneous messages in the CiscoWorks Log Manager.

On your worksheet, indicate whether you want the script to erase applications using the facility.

Enabling the CiscoWorks Log Purging Utility

CiscoWorks contains a centralized log file called *nmslog*. This log file can be automatically purged and backed up every day. As a result, the log purging utility is started automatically by the UNIX **cron** daemon. (A **daemon** is a UNIX process that repeatedly runs in the background, independent of any user's workstation or terminal.)

On your worksheet, indicate whether you want the *nmslog* file to be purged and backed up automatically.

Additional Information for Configuring an Upgrade

If you are upgrading from an existing version of CiscoWorks, the configuration script prompts you for additional information. Enter this information in the section “Additional Information for an Upgrade Configuration,” at the end of the worksheet.

Installing New MIB Files and Saving Old MIB Files

The CiscoWorks software contains new MIB files. Upon installation, any MIB files that already existed on your system are automatically backed up in a file called *mibs.bak* in the *\$NMSROOT/etc* directory under the appropriate CiscoWorks directory.

Check the box on the worksheet to indicate that you want to save your old MIB files.

Replacing the Startup Commands

You can specify whether you want the CiscoWorks daemons and the Sybase dataserver to be started automatically whenever the system is rebooted. If you allow them to be started automatically, the startup commands are added to the file named */etc/rc.local*. Otherwise, you need to perform this task manually.

On your worksheet, indicate whether you want the CiscoWorks daemons and Sybase dataserver to be started automatically.

Becoming a Superuser

To perform the tasks associated with installing and configuring CiscoWorks, you must log into your system as a superuser (*root*). Being a superuser allows you to perform functions restricted from normal users.

Caution If you are a relatively inexperienced UNIX user, limit your activities as a superuser to the tasks described in this publication. As a superuser, you can adversely affect your operating environment if you are unaware of the effects of the commands you use.

To become a superuser, you must know the root password. In the following examples, the root password is *rootpassword*.

Note This discussion assumes that you use the C shell (csh). If you are using the C shell, the prompt usually displays as a pound sign (#) when you are logged in as superuser. If you are using the Bourne shell, the prompt usually displays as a dollar sign (\$).

If you are not logged in, enter the following commands to log in as a superuser:

```
login: root
Password: <rootpassword>
hostname#
```

The UNIX prompt is usually represented by a # sign, indicating that you are logged in as a superuser.

Note For security reasons, when you enter the root password, nothing appears on the screen.

If you are already logged in, but not as root, enter the following commands to change your login to root:

```
hostname% su
Password: <rootpassword>
hostname#
```

The UNIX prompt changes to a # sign, indicating that you are logged in as a superuser.

Upgrading to CiscoWorks 2.1

The upgrade option only applies to existing versions of CiscoWorks 2.1. If you have an existing version of CiscoWorks 2.1 only, you can upgrade to a later version of 2.1 by following the procedures outlined in this section.

Note If you are using a version of CiscoWorks that is earlier than 2.1, you must install CiscoWorks 2.1 as if you are performing a brand-new installation of CiscoWorks (refer to “Installing CiscoWorks Software for the First Time” in Chapter 3, of this guide).

Shutting Down the Sybase Database

CiscoWorks accesses the Sybase database, so you must close all database files and shut down your database before starting the backup process. If you do not perform these steps before you perform your backup, the integrity of your backup cannot be ensured.

To shut down the database, perform the following steps:

Step 1 Log into your system as a superuser.

Step 2 Depending on where you installed Sybase, enter one of the following at your UNIX prompt.

If Sybase is installed in `$NMSROOT`, enter

```
hostname# setenv SYBASE $NMSROOT/sybase
```

If you specified a different directory for Sybase, enter

```
hostname# setenv SYBASE Sybase_directory
```

Step 3 Execute the `isql` binary by entering the following:

```
hostname# $SYBASE/bin/isql -Usa -P password
```

If you have changed the password for the Sybase sa account, enter that password. If you have not changed the password, do not supply a password.

After starting isql, the prompt 1> displays.

Step 4 Enter the **shutdown** command as follows:

```
1> shutdown  
2> go
```

The database shuts down, and the UNIX prompt displays. Continue to the next section for instructions on backing up your CiscoWorks data.

Backing Up Your Existing CiscoWorks Software

Back up your entire CiscoWorks system, including the *\$NMSROOT* directory, current database and map files, as well as any additional Sybase data files. For information on making backups of UNIX files, refer to the UNIX manual pages on **tar(1)** or **cpio(1)**.



Caution To prevent any possible data loss, back up your system and database before installing CiscoWorks.

Verifying Installation of SunOS and HP OpenView

After you shut down the Sybase database and back up your existing CiscoWorks software, follow the instructions in the Sun documentation to upgrade your version of SunOS to Version 4.1.2 or 4.1.3. After you install SunOS Version 4.1.2 or later, follow the instructions in your HP OpenView documentation to install HP OpenView.

Setting Up TFTP

The Trivial File Transfer Protocol (TFTP) enables you to transfer files between your system and other devices on your network that use the Simple Network Management Protocol (SNMP). You can use TFTP with several CiscoWorks applications (Configuration Management, Configuration Management Batch Program, AutoInstall, Software Library Manager, Device Software Manager, and Configuration Snap-In Manager, to transfer files.

You must verify that the TFTP daemon is enabled, the TFTP environment variable is set correctly, and a TFTP boot directory exists. Instructions for these tasks follow.

Enabling the TFTP Daemon

You can verify that TFTP daemon is enabled by completing the following steps:

Step 1 Log in as a superuser.

Step 2 Using a text editor such as *vi* , edit the */etc/inetd.conf* file.

Step 3 Look in the file */etc/inetd.conf* for the line that invokes *tftpd*. If the line begins with a pound sign [<#], remove the sign with your text editor. Depending on your system, the line that invokes the TFTP daemon may look similar to the following:

```
#tftp dgram udp wait root /user/etc/in.tftpd in.tftpd -s /tftpboot
```

Step 4 Save the changes to the edited file and exit your text editor.

Step 5 At the UNIX prompt, enter the following command to display the process identification number for the *inetd* configuration.

```
hostname# ps -ax | grep -v grep | grep inetd
```

The system response is similar to the following:

```
119 ? S 0:05 inetd
```

The first number in the output is the process ID of the *inetd* configuration.

Step 6 To enable your system to read the edited */etc/inetd.conf* file, enter the following command:

```
hostname# kill -HUP 119
```

Step 7 Verify that TFTP is enabled by entering the following:

```
hostname# netstat -a | grep tftp
```

The output should be similar to the following:

```
udp 0 0 *.tftp *.*
```

If there is no output, TFTP is not enabled.

For additional information on TFTP, refer to the UNIX manual pages on the **tftp** and **tftpd** commands.

Setting the *TFTPTYPE* Environment Variable

TFTPTYPE is an environment variable used by the *ncsconfigure* script to indicate which type of TFTP is being used. The Sun TFTP daemon requires that a file that is being transferred must first exist as a “dummy” file on the system. Other implementations require that the file does not exist on the system.

TFTPTYPE can take the value OVERWRITE (the file must exist and is overwritten) or NOOVERWRITE (the file cannot be overwritten; it must not exist). If you are using the standard Sun TFTP daemon, no action is required to set the *TFTPTYPE* variable. Otherwise, you must set *TFTPTYPE* accordingly.

Creating the TFTP Boot Directory

To save and store configuration files that are loaded to a device when using CiscoWorks applications supported by TFTP, use the */ftpboot* directory (on Sun workstations).

Creating and using the TFTP boot directory on your system is optional. The TFTP boot directory is accessible by all users. To protect the security of your system and limit access to it, you can choose not to set up this directory on your system. However, without a TFTP boot directory, you will be unable to use the following CiscoWorks applications: AutoInstall Manager, Configuration Management, and the Device Software Manager.

Note If you want to use the CiscoWorks Software Library Manager or Device Software Manager application to manage device software, you should allocate at least 4 MB of space to the TFTP boot partition.



Timesaver If you upgraded from an earlier version of CiscoWorks, the TFTP boot directory might already exist on your system. In that case, you need not perform these steps.

To create the TFTP boot directory, perform the following steps:

Step 1 If the TFTP boot directory does not exist, enter the following command to create it:

```
hostname# mkdir /tftpboot
```

Step 2 The */tftpboot* directory must have the appropriate permissions. Modify the permissions with the following command:

```
hostname# chmod 777 /tftpboot
```

As a result, all users accessing the TFTP boot directory will have read, write, and execute permissions.

After completing the worksheets and other preparations required to install CiscoWorks, proceed to Chapter 3, “Installing and Configuring CiscoWorks” for instructions on installing and configuring the CiscoWorks software. If you want to learn about customizing your system, read the following section on “Modifying Your .Xdefaults File.”

Modifying Your .Xdefaults File

Some operations of CiscoWorks and HP OpenView Windows are determined by X Windows. As such, you can customize the way you work with CiscoWorks on HP OpenView by modifying your *.Xdefaults* file. For example, you can change the colors that HP OpenView Windows displays by changing your X Windows environment (Refer to your *HP OpenView Windows User’s Guide*). Or, you can specify certain ways in which CiscoWorks runs in your X Windows environment.

This section provides information on the following topics:

- Customizing CiscoWorks Colors and Fonts
- Editing the *.Xdefaults* File Entry to Specify the Text Editor
- Enabling Boot File Generation
- Updating the Refresh Interval in the CiscoWorks Log Manager Window
- Resetting the Default Window Size of CiscoWorks Applications

Customizing CiscoWorks Colors and Fonts

All of the X resources used by CiscoWorks applications are customizable, including colors and fonts. By overwriting the default resources used in CiscoWorks, you can customize the colors and fonts to meet your needs. To use your own colors and fonts for CiscoWorks, perform one of the following procedures:

- Store your resources in the */usr/lib/X11/app-defaults/XCiscoWorks* file.
- Rename your resource file to *\$HOME/XCiscoWorks*.
- Store your resources in the *\$HOME/.Xdefaults* file.
- Start your CiscoWorks applications with your specified resource options (for example, **-font 9x15bold**).

Editing the .Xdefaults File Entry to Specify the Text Editor

Defining the look of your text editor window requires that you add the following command to the *.Xdefaults* file, substituting the appropriate options:

Step 1 Confirm that X Windows is running. You can always start an X window by entering the **x11start** command at the UNIX prompt.

Step 2 Using your text editor, open your *.Xdefaults* file. The *.Xdefaults* file is usually stored in your home directory. For example, if you are using **vi** as your text editor, enter the following command:

```
vi $HOME/.Xdefaults
```

Step 3 Add the following command:

```
* EditorFormat:command string %s
```

Step 4 Similarly, to specify the emacs editor in */usr/local/bin*, add the following line to the *.Xdefaults* file:

```
* EditorFormat:/usr/local/bin/emacs %s
```

Enabling Boot File Generation

Enabling boot file generation is a matter of editing the *.Xdefaults* file to specify the “on” state. To specify the “on” state, perform the following steps:

Step 1 Confirm that the X Window is running. You can always start an X window by entering the **x11start** command at the UNIX prompt.

Step 2 Using your text editor, open your *.Xdefaults* file. The *.Xdefaults* file is usually stored in your home directory. For example, if you are using **vi** as your text editor, enter the following command:

```
vi $HOME/.Xdefaults
```

Step 3 Add the following line to the *.Xdefaults* file in your home directory:

```
*Bootfile:on
```

Updating the Refresh Interval in the CiscoWorks Log Manager Window

Your CiscoWorks Log Manager redraws, or refreshes, its window according to a default interval of 900 seconds. You can customize the frequency of this process by modifying the *.Xdefaults* file. To change the refresh interval of the Log Manager window, perform the following steps:

Step 1 Confirm that the X Window is running. You can always start an X window by entering the **x11start** command at the UNIX prompt.

Step 2 Using your text editor, open your *.Xdefaults* file. The *.Xdefaults* file is usually stored in your home directory. For example, if you are using **vi** as your text editor, enter the following command:

```
vi $HOME/.Xdefaults
```

Step 3 Add the following line to your *.Xdefaults* file

```
XCiscoworks*refreshInterval:new interval in seconds
```

For example, if you want to reset the refresh interval to 450 seconds, enter the following line to your *.Xdefaults* file:

```
XCiscoWorks*refreshInterval:450
```

Resetting the Default Window Size of CiscoWorks Applications

When working with CiscoWorks applications, you may notice that the window sizes may vary from application to application. The layout of the window and the size of its text and graphics is preset to be large enough to contain all the elements that define the window. However, you can resize the window without obscuring the text.

To reset the default CiscoWorks window size, perform the following steps:

Step 1 Confirm that X Windows is running. You can always start an X window by entering the **x11start** command at the UNIX prompt.

Step 2 Use a text editor such as *vi* to open the *\$HOME/XCiscoWorks* file.

Step 3 Add the following line to your *\$HOME/XCiscoWorks* file:

```
"XCiscoWorks*geometry: 500x400+0+0"
```

Step 4 Enter the following command:

```
xrdb -merge < ~/XCiscoWorks
```