

Preparing to Install CiscoWorks

This chapter describes how to prepare for CiscoWorks installation and configuration.

Before you install the CiscoWorks network management software, confirm that your computer system meets the related hardware and software version requirements. In addition, you should note any special requirements about how you want CiscoWorks installed.

Verifying Your System Requirements

Before you install CiscoWorks on your system, make sure that your system meets the general requirements as described in Table 2-1.

Table 2-1 General System Requirements for CiscoWorks 2.1(2)

Operating System	Free Hard Disk Space	RAM	Swap Space	Free Root Partition
IBM AIX Version 3 Release 2.5	1,000 MB	64 MB (minimum)	128 MB	5 MB

The memory and swap space requirements of CiscoWorks depend on such factors as which applications you want to run, the number of applications you want to run concurrently, and the number of network devices that you want to manage with CiscoWorks. As a result, you might need to increase the swap space beyond the general minimum requirements, depending on your particular network management needs.

Additional Hardware Requirements

- In addition to the general system requirements, CiscoWorks requires the following hardware:
- IBM RISC System/6000 workstation, Model 340 or higher
 - Color monitor
 - CD-ROM drive that is local to the workstation or available remotely through the network
 - PostScript-compatible printer (in order to print window images)

Additional Software Requirements

In addition to the general system requirements, CiscoWorks requires the following software:

- X Window System Version 11 Release 5
- Motif Version 1 Release 2
- NetView for AIX Version 3

Several CiscoWorks applications have specific Cisco Systems software requirements. For more information, refer to the *CiscoWorks User Guide*. The Configuration Management application, for example, requires Cisco Systems Software Release 8.2 or later.

Depending on the router you are using, the Device Software Manager application requires a specific router system software, as shown in Table 2-2.

Table 2-2 Router and Software Requirements for Use with Device Software Manager

Cisco Router Type	Router System Software Requirement
Cisco 2500	Software Release 9.14(4)-9.14(8) or later
Cisco 3000	Software Release 9.1(7.5) or later, or 9.1(8) or later
Cisco AGS+	Software Release 9.1(7.5) or later, or 9.1(8) or later
Cisco 4000	Software Release 9.14(3.4) or later
Cisco 7000	Software Release 9.17(5.2) or later
All Cisco routers (collection of Cisco 3000, Cisco 4000, Cisco 7000, or AGS+ routers)	Software Release 9.21(0.26) or later; 9.21(1) or later; or 9.1(8) or later
Cisco 7000 routers on which you want to perform microcode upgrades	Software Release 9.17(5.2) or later; 9.21(0.32) or later

Gathering Information for Installation and Configuration

Before you install and configure CiscoWorks, identify and gather the information required to perform the installation and configuration as outlined in the following sections.

Installation Items

The following information is required for the installation of CiscoWorks. To obtain and verify system information for some items, you need to be logged in as a superuser. For information on how to log in as a superuser, refer to the section “Becoming a Superuser” in Chapter 3.

Verify the following information before installing CiscoWorks:

- AIX Requirements
- Hard Disk Space
- Configuring TFTP for Device Configuration Management
- CD-ROM Drive Location
- Remote Installation
- RAM
- Swap Space
- Checking the .rhosts File

AIX Requirements

Your workstation must be running AIX Version 3 Release 2.5 before you can install CiscoWorks. To determine which version of AIX you are using, enter the following command at the prompt:

```
hostname% oslevel
```

Output similar to the following will appear:

```
Processing.....Please Wait.  
>3250
```

Hard Disk Space

CiscoWorks requires 1,000 MB of disk space in the */usr* filesystem on your workstation.

To find out how much disk space is available on your system, enter the following at the command prompt:

```
hostname% df -i
```

Output similar to the following will appear:

Filesystem	Total KB	used	free	%used	Mounted on
/dev/hd4	16384	10008	6376	61%	/
/dev/hd9var	32768	3756	29012	11%	/var
/dev/hd2	1003520	871324	132196	86%	/usr
/dev/hd3	16384	732	15652	4%	/tmp
/dev/hd1	4096	240	3856	5%	/home
/dev/hd10	16384	544	15840	3%	/usr/sys
/dev/lv00	2002944	586868	1416076	29%	/disk

The amount of disk space available in each filesystem is displayed. If you do not have at least 1,000 MB of space in your */usr* filesystem, you must create a filesystem with the mount point of */usr/nms*.



Caution CiscoWorks can only be installed in */usr/nms*. If you create a filesystem, its mount point must be */usr/nms*. If */usr/nms* already exists on your system, you must back up all the data in that directory before installing CiscoWorks. Installation of CiscoWorks will overwrite any existing data.

The following overview summarizes the steps involved in creating a filesystem:

- Step 1** Create an empty filesystem.
- Step 2** Verify the integrity of the empty filesystem.
- Step 3** Create a mount point directory.
- Step 4** Configure the filesystem table and edit the */etc/filesystems* file.
- Step 5** Mount the new filesystem.

For more information, refer to your IBM documentation or the manual pages on **mkfs**, **fsck**, **mkdir**, and **mount**. If you are unfamiliar with repartitioning disks or creating filesystems, contact a knowledgeable system administrator.

RAM

CiscoWorks requires a minimum of 64 MB of RAM. To find out how much RAM is available on your system, make sure you are logged in as a superuser. (Refer to the section “Becoming a Superuser” in Chapter 3.) Enter the following command at the UNIX prompt:

```
hostname# lscfg | grep mem
```

Output similar to the following appears:

```
+ mem0          00-0B          32 MB Memory Card
+ mem1          00-0C          32 MB Memory Card
```

If your workstation does not have at least 64 MB of RAM, upgrade its memory.

Swap Space

CiscoWorks requires 128 MB of swap space on your system.

To find out how much swap space is available on your system, make sure you are logged in as a superuser. (Refer to the section “Becoming a Superuser” in Chapter 3.) Enter the following command at the prompt:

```
hostname# lspv -a
```

Output similar to the following appears:

Page Space	Physical Volume	Volume Group	Size	%Used	Active	Auto	Type
paging00	hdisk1	external	160MB	17	yes	no	lv
hd6	hdisk0	rootvg	80MB	41	yes	yes	lv

Add the numbers in the “Size” column to determine your system’s total swap space. In the previous example, the system’s swap space is 240 MB.

If the swap space on your system is less than 128 MB, expand the swap space by following the instructions in your IBM documentation.

Configuring TFTP for Device Configuration Management

After CiscoWorks is installed and configured, you can use several applications (Configuration Management, Configuration Management batch program, AutoInstall Manager, Software Library Manager, Device Software Manager, Configuration Snap-In Manager, and Sync w/Sybase) with the Trivial File Transfer Protocol (TFTP). With TFTP and CiscoWorks, you can transfer configuration files and software images between your system and other devices on your network that use the Simple Network Management Protocol (SNMP).

In order for TFTP to operate, you must follow the instructions in the sections “Creating the TFTP Boot Directory” and “Setting Up TFTP” later in this chapter. You can perform these tasks before or after CiscoWorks installation and configuration.

CD-ROM Drive Location

You can install CiscoWorks from a local or remote CD-ROM drive.

Remote Installation

If you are planning to install CiscoWorks from a CD-ROM drive attached to a remote system, find out whether you have a login account as a superuser on that system. If you do not have superuser access to the remote system, contact the system administrator of the remote system to obtain a login account with superuser access to that system.

If you are installing CiscoWorks from a remote CD-ROM drive, obtain the complete host name of the remote system and make sure that the host name is listed in the */etc/hosts* file on your system.

Checking the .rhosts File

The *.rhosts* file enables users to log into another user account on a remote system. If you plan to install CiscoWorks from a remote CD-ROM drive, the *.rhosts* file on that system must contain the host name of your local system and your username specified as a superuser. To verify the local host name and that your username is specified as superuser, access the *.rhosts* file by using a text editor such as *vi*.

For more information on the *.rhosts* file, refer to your IBM AIX documentation.

Configuration Items

This section explains the information required for the configuration of CiscoWorks. For more information on the */etc/passwd* and */etc/group* files, usernames, user IDs, group names, and group IDs, refer to your IBM documentation.

You will need to specify the following items during the configuration process:

- CiscoWorks Group Name
- Usernames for CiscoWorks Group
- Log File for CiscoWorks Messages
- Enabling the CiscoWorks Log Purging Utility
- Erasing Applications that Use the Syslog Facility
- Syslog Facility for CiscoWorks Messages
- TACACS Information

CiscoWorks Group Name

In order for CiscoWorks users to access and use CiscoWorks, they must belong to a CiscoWorks group that is specified in the */etc/group* file on your system. During configuration, you supply the group name you want to use for CiscoWorks users. The default name for the group is *cscworks*.

During CiscoWorks configuration, you can add new users directly to the *cscworks* group. As a result, you can add new users to the *cscworks* group during the configuration process without editing the */etc/group* file. However, to add a new user after performing the CiscoWorks configuration, you need to edit the */etc/group* file.

Username for CiscoWorks Group

In order to specify usernames during configuration to allow users to access and use CiscoWorks, the following prerequisites apply:

- A user must have a login account on the workstation.
- The login account information for each user must exist in the */etc/group* and the */etc/password* files on the system.

If you need to create user login accounts, refer to your AIX documentation.

Log File for CiscoWorks Messages

The CiscoWorks Log Manager application uses a default centralized log file, */var/log/nmslog*, which gets messages from the UNIX *syslogd* process. If you want these messages to be logged to a different file, you can specify a different filename.

Syslog Facility for CiscoWorks Messages

The CiscoWorks Log Manager application uses a centralized log file that gets messages from the UNIX *syslogd* process. The default facility is *local7*.

If you want to log both CiscoWorks messages and Cisco device messages and view them through the Log Manager application, use the default facility *local7*. Cisco routers use the *local7* facility. If you specify a facility in the range of *local0* through *local6*, only CiscoWorks messages are logged.

Information about the facility you choose will be stored in the *\$NMSROOT/etc/nms.rc* file. At a later time, you can change the facility you use by modifying the */etc/rc* file and either setting the *NMSYSLOG* environment variable or editing the *nms.rc* file. For instructions on performing these tasks, refer to the *CiscoWorks User Guide*.

Erasing Applications that Use the Syslog Facility

During configuration, you will be asked whether you want to erase any other applications that are using this facility. If you answer no, the CiscoWorks log utility might not be able to use the Syslog facility to do the following:

- Transfer or exchange information such as error messages.
- Receive extraneous messages in the CiscoWorks Log Manager.

Enabling the CiscoWorks Log Purging Utility

CiscoWorks contains a centralized log file called *nmslog*. This log file can be automatically purged and backed up every day. As a result, the log purging utility is started automatically by the UNIX **cron** daemon. (A *daemon* is a UNIX process that repeatedly runs in the background, independent of any user's workstation or terminal.)

TACACS Information

CiscoWorks provides support for Terminal Access Controller Access Control System (TACACS). TACACS is an authentication protocol that requires users to supply a username and password in order to access Cisco devices.

Setting Up a TACACS Server

During CiscoWorks configuration, you must indicate whether your workstation will be set up as a TACACS server.

Starting TACACS Daemon during System Reboot

If you set up your network system as a TACACS server, the TACACS daemon startup facility will automatically be added to the */etc/rc* file. During configuration, if you set up a TACACS server, you are asked whether you want the TACACS daemon to start automatically when you restart the system. If you answer no, the TACACS daemon will be added to your */etc/rc* file but will be commented out.

TACACS Username

If you elect to set up a TACACS server, you need to supply a username in the appropriate field during configuration. The username you supply here is the one that is provided when you remotely log in to manage Cisco devices.

TACACS Password

If you elect to set up a TACACS server, you need to supply a TACACS password.

Using Extended TACACS Mode

The TACACS extended account, named *\$enable\$*, is used to access routers that use the extended TACACS mode. For more information on the *\$enable\$* account, see the *CiscoWorks User Guide*.

Extended TACACS Mode Password

If you answered “Y” to accept an extended TACACS mode, you are then prompted to supply the password for the special TACACS *\$enable\$* account.

Creating the TFTP Boot Directory

To save and store configuration files that are loaded to a device when using CiscoWorks applications supported by TFTP, create a TFTP boot directory.

Creating and using the TFTP boot directory on your system is optional. The TFTP boot directory is accessible by all users. To protect the security of your system and limit access to it, you can choose not to set up this directory on your system. However, without a TFTP boot directory, you will be unable to use the following CiscoWorks applications: AutoInstall Manager, Configuration Management, and the Device Software Manager.

Note If you want to use the CiscoWorks Software Library Manager or Device Software Manager application to manage device software, you should allocate at least 4 MB of space to the TFTP boot partition.

To create the TFTP boot directory, perform the following steps:

Step 1 If the TFTP boot directory does not exist, enter the following command to create it:

```
hostname# mkdir /tftpboot
```

Step 2 The TFTP boot directory must have the appropriate permissions. Modify the permissions with the following command:

```
hostname# chmod 777 /tftpboot
```

Step 3 Edit the */etc/passwd* file so that the tftp user's home directory is */tftpboot*.

As a result, all users accessing the TFTP boot directory will have read, write, and execute permissions.

After verifying all of the requirements to install CiscoWorks, proceed to Chapter 3, "Installing and Configuring CiscoWorks" for instructions on installing and configuring the CiscoWorks software.

Setting Up TFTP

The Trivial File Transfer Protocol (TFTP) enables you to transfer files between your system and other devices on your network that use the Simple Network Management Protocol (SNMP). You can use TFTP with several CiscoWorks applications (Configuration Management, Configuration Management Batch Program, AutoInstall, Software Library Manager, Device Software Manager, and Configuration Snap-In Manager) to transfer files.

You must verify that the TFTP daemon is enabled, the TFTP environment variable is set correctly, and a TFTP boot directory exists. Instructions for these tasks follow.

Enabling the TFTP Daemon

Use System Management Interface Tool (SMIT), an IBM AIX system administration facility, to enable the TFTP daemon. For additional information on TFTP, refer to the UNIX manual pages on the **tftp** and **tftpd** commands. Enable the TFTP daemon by completing the following steps:

Step 1 Log in as a superuser.

Refer to "Becoming a Superuser" in Chapter 3.

Step 2 Start SMIT by entering the following at the command prompt:

```
hostname# smit
```

The main SMIT window appears, as shown in Figure 2-1.




Figure 2-1 Main SMIT Window

- Step 3** Select **Communications Applications and Services**.
- Step 4** Select **TCP/IP**.
- Step 5** Select **Further Configuration**.
- Step 6** Select **Server Network Services**.
- Step 7** Select **Other Available Services**.
- Step 8** Select **Super Daemon (inetd)**.
- Step 9** Select **inetd Subservers**.
- Step 10** Select **Change/Show Characteristics of an inetd Subserver**.

Step 11 From the Single Select List window that appears, select **tftp**.

Step 12 Add **-d /tftpboot** to the entry displayed in the Service Program Command Line ARGUMENTS field.

Step 13 Click on **Do**.

A window with a figure in the upper right corner will appear. When the process is completed successfully, the figure will raise its arms.

Step 14 Click on **Done**.

The TFTP daemon is now set and enabled.

Step 15 Select **Exit>Exit SMIT**.

Step 16 Verify that the TFTP daemon is enabled by entering the following at the command prompt:

```
hostname# grep tftp /etc/inetd.conf
```

Output similar to the following will appear:

```
tftp dgram udp wait nobody /etc/tftpd tftpd -n -d /tftpboot
```