Network Maintenance

This chapter describes some of the tools provided for detecting and identifying network and/or equipment problems that are available to the network operator.

There are considerably more advanced tools built into the system software that are available only to StrataCom personnel, such as ISC. These advanced tools require in-depth knowledge or the hardware and software and are used generally to locate the less common types of system problems.



Caution Do not perform any disruptive tests or repairs to the network on your own. Before commencing with troubleshooting, call StrataCom ISC so that they can provide you with assistance in locating a fault.

Automatic Alarm Reporting

In a network with BPX, IGX, and IPX nodes, it is recommended that at least one node be configured to transmit alarms automatically to the StrataCom International Support Center (ISC). Figure 6-1 illustrates the hardware configuration required for implementation.

When an alarm occurs on the network, the autodial modem automatically dials the specified telephone number. An auto-answer modem at StrataCom ISC answers the call and directs it to a dedicated personal computer. The alarm is logged under the network ID (an ASCII character string) specified by the network administrator and approved by ISC personnel.

If the auto-answer modem at ISC is busy when an alarm arrives, then the autodial modem will keep dialing until the call is completed. A suggested modem is the Codex V.34 RSA 28.8 Kbaud modem. Connections to the node are detailed in the appropriate *BPX Reference Manual* or *IPX Reference Manual*.



Figure 6-1 Automatic Alarm Reporting to ISC

Network Troubleshooting

The BPX, IGX, and IPX system software provides a variety of tools for monitoring the network and detecting and locating network and system problems. Almost all network troubleshooting can be performed from the console of the StrataView Plus Network Management Station (NMS). These tools are described in general in the following paragraphs.

Note For more specific information on using the various commands referenced in this section, refer to the BPX/IPX Command Reference Manual. For details on the StrataView Plus NMS, refer to the StrataView Plus User's Guide.

The StrataView NMS displays a map of the network topology indicating where the nodes are located and the packet trunks that provide the connections between the nodes (refer to Figure 6-2). This topology map displays, in color, any network faults detected by the system.

All nodes in the network are accessible from the StrataView Plus NMS and any network or system fault detected will be reported to the NMS. In addition the network operator can access any routing node in the network by using a Virtual Terminal (vt) command to create a virtual connection from the NMS console directly to the desired node. Non-routing nodes are accessed via "telnet" command on a LAN interface, and are managed via in-band SNMP. This allows the operator to enter commands and view system status as if he were locally connected to the node.



Figure 6-2 Example of a StrataView Plus Topology Map

Displaying Network Alarms

Whenever an alarm condition is detected in the network, the NMS console will sound an alarm tone, a Major Alarm or Minor Alarm notice will flash, and one or more of the icons on the topology map will change color to alert the network operator of the fault. Additionally, each node can be equipped to output a set of relay contact closures to operate customer alarm systems to notify network operators of an alarm condition in the network. See *IPX Reference Manual* or the *BPX Reference Manual* for information.

Another method of identifying the location of a network alarm is to issue a Display Networks (**dspnw**) command (Figure 6-3) A Major or Minor alarm indication after one or more of the node names will be displayed if there is an alarm anywhere in the network. This screen will identify the node(s) that detected the alarm condition.

bpxb	VT	YourID:1	BPX 15	8.1.1	Dec.	9 1995	14:34	PSI
NodeName	Alarm	Trunk	Trunk		Trur	ık		
bpxa		1.1-1.1/bpxe	6.2-3.2	2/bpxc	5.1-	-6.1/bpx	b	
		6.1-11.2/bpxd	1.2-5.2	l/bpxb	1.3-	-1.3/bpx	c	
		5.2-12.2/bpxg						
bpxb		6.1-5.1/bpxa	5.1-1.2	2/bpxa	6.2-	-3.1/bpx	C	
		4.1-4.1/bpxc	4.2-4.2	2/bpxc	4.3-	-4.3/bpx	C	
		5.3-1.2/bpxe						
bpxc		3.2-6.2/bpxa	3.1-6.2	2/bpxb	2.1-	-14.1/bp	xd	
		2.2-16/ipxb	2.3-14	.3/bpxd	1.3-	-1.3/bpx	a	
		4.1-4.1/bpxb	4.2-4.2	2/bpxb	4.3-	-4.3/bpx	b	
bpxd		14.1-2.1/bpxc	14.2-3,	/ipxa	14.3	3-2.3/bp	XC	
		11.2-6.1/bpxa						
bpxe		1.1-1.1/bpxa	1.2-5.3	3/bpxb	1.3-	-2.1/bpx	f	
bpxf	Minor	2.1-1.3/bpxe						

Figure 6-3 Display Network Screen

This Command: dspnw

Continue?

Next Command:

Once the location (node) where the alarm has been detected is identified, the network operator can use the Virtual Terminal feature to observe the status at that location. The Display Alarms (**dspalms**) command and associated screen will be used here. Figure 6-4 illustrates a Minor Alarm at a node named D1.beta.

Figure 6-4 Display Alarms Screen

bpxf	VT	YourID:1	BPX 15	8.1.1	Dec. 9	1995	14:36 PST
Alarm summary	(Con:	figured alarm	slots: Non	e)			
Connections Fa:	iled:	None					
Groups Failed:		None					
TRK Alarms:		None					
Line Alarms:		None					
Cards Failed:		None					
Slots Alarmed:		None					
Missing Cards:		None					
Remote Node Ala	arms:	None					
Remote Domain A	Alarms	: None					
Interface Shelf	f Aları	ms: 1 Minor					
ASM Alarms:		None					

Last Command: dspalms

Displaying Trunk and Circuit Line Status

If the Display Nodes (**dspnds**) or Display Network (**dspnw**)) command screen indicates a service-affecting problem with either a network trunk or customer circuit line, there are two similar screens that will display their status. Figure 6-5 illustrates an example of the Display Trunk (**dsptrks**) command screen with a Major Alarm on trunk 5.2. It also indicates whether the alarm is a Red (Local) or Yellow (Remote) alarm.

Figure 6-5 Display Trunk Status Screen

bpxb	VT	YourID:1	BPX 15	8.1.1	Dec.	9 1995	14:44	PST
TRK Type 4.1 E3 4.2 E3 4.3 E3 5.1 T3 5.2 T3 5.3 T3 6.1 OC3 6.2 OC3	Curre Clear Clear Clear Clear Major Clear Clear	ent Line Alarm S - OK - OK - OK - OK - Loss of Sig - OK - OK - OK	(RED)		Other bpxc/4 bpxc/4 bpxa/2 axis32 bpxe/2 bpxa/9	End 4.1 4.2 4.3 1.2 1(AXIS) 1.2 5.1		
0.2 000	01Cur	011			~ <u>r</u> 210/.			

Last Command: dsptrks

Figure 6-6 illustrates an example of the Display Lines (dsplns) command screen with a Major Alarm on line 12.2. It also indicates whether the line alarm is a Red (Local) or Yellow (Remote) alarm.

Figure 6-6 Display Line Status Screen

bpxb	VT	YourID:1	BPX 15	8.1.1	Dec.	9 1995	14:51 PST
Line Type 10.1 E3 10.2 E3 12.1 T3 12.2 T3 13.1 T3 13.2 T3 14.1 OC3 14.2 OC3	Curre Clear Clear Major Clear Clear Clear Clear	nt Line Alarm 8 - OK - OK - OK - - OK - OK - OK - OK	Status				

Last Command: dsplns

Network trunk and line inputs to each node are constantly monitored for error conditions such as loss of signal, bipolar errors, frame errors, etc. These trunk and line errors may not be severe enough to cause a Red or Yellow Alarm but can be observed using the Display Trunk Errors (**dsptrkerrs**) and Display Line Errors (**dsplnerrs**) command screens. Figure 6-7 illustrates a typical summary trunk errors screen. Errored tens of seconds statistics are also kept and are displayed by a second trunk or circuit line screen.

Figure 6-7 Display Trunk Errors Screen

bpxc		VT	StrataCom	n I	3PX 15	8.1.1	Dec.	9 1995	14:59	PSI
Total	Errors									
	Code	Rx Cell	Out of	Loss of	Frame	HCS	Tx Cell	Cell	Cell	
TRK	Errors	Dropped	Frames	Signal	BitErrs	Errors	Dropped	Errors	Oofs	
1.1	0	0	0	0	-	0	0	-		-
1.3	0	0	0	0	-	0	0	-		-
2.1	0	0	0	0	-	0	0	-		-
2.2	0	0	0	0	-	0	0	-		-
2.3	0	0	0	0	-	0	0	-		-
3.1	-	0	0	0	-	0	0	-		-
3.2	-	0	0	0	-	7	0	-		-
4.1	0	0	0	0	-	0	0	-		-
4.2	0	0	0	0	-	0	0	-		-
4.3	0	0	0	0	-	0	0	-		-

Last Command: dsptrkerrs

Next Command:

Displaying Node Status

The system software automatically determines the card configuration of the node and displays the card type in each shelf slot. Each card is shipped with a model and revision number burned into Read-Only Memory to assist in tracking each individual card for inventory purposes.

Each card in a node is periodically tested in a background mode so as not to disrupt normal traffic. A short, automatic self-test is performed to identify card failures and, if the node is equipped with a redundant card set, transfer operation to the alternate card before any downtime is detected. The Display Cards (**dspcds**) screen, Figure 6-8, shows what cards are equipped and their status: active, failed, or standby (for redundant card sets).

bpz	кb		VT	YourID	:1	BPX	15	8.1.1	1	Dec.	9 1995	15:06 PST
	FrontCa	ard	BackC	ard				FrontCa	ard	Back	Card	
	Туре	Rev	Type	Rev	Status			Туре	Rev	Type	Rev	Status
1	Empty						9	Empty				
2	Empty						10	ASI-E3	JA11	E3-2	BE	Active
3	Empty						11	Empty				
4	BNI-E3	CD03	E3-3	BE	Active		12	ASI-T3	JA11	т3-2	BE	Active
5	BNI-T3	CB04	T3-3	AA	Active		13	ASI-T3	JX11	Т3-2	BE	Active
б	BNI-OC	ЗВНА	MMF-2	AH	Active		14	ASI-OC	3BWA	MMF-	2 DJ	Active
7	BCC	AVC	LMBCC	P01	Standby		15	ASM	ACA	LMAS	M P01	Active
8	BCC	A0405	LMBCC	AC	Active							

Figure 6-8 Display Cards Screen

Last Command: dspcds

Next Command:

If any card is removed for any reason, including replacement, the node configuration database will remember what type of card was initially installed in each slot to minimize the possibility of installing the wrong card type in a slot.

Additionally, all node power supply voltage outputs are monitored and an alarm is generated if any output fails or if any voltage falls out of tolerance. The status of each power supply in the node is displayed on the Display Power Supply Status (**dsppwr**) command screen (Figure 6-9).

Each node is cooled by various fan assemblies. In the IPX and IGX cabinets and in the BPX enclosure, there is a temperature sensor that monitors the ambient temperature inside the enclosure. If there should be a failure of one or more of the fans, causing the temperature to rise, an alarm will be generated so the fan or assembly can be replaced before the temperature exceeds the maximum allowed. The cabinet temperature can be observed in the IPX, IGX, and BPX on the dsppwr command screen. In addition, the BPX provides a Display Assembly Modules (**dspasm**) screen.

bpxb	VT YourID:1	BPX 15	8.1.1	Dec.	9 199	5 15	:09 P	ST
Power	r Status			Cal	binet	Temp	eratu	re
ASM Status: Ac	ctive				31		87	
Power voltage	A/B: 0 / 48 V			C	60		140	F
PSU Ins Type A N N/A	Rev SerNum Failure N/A N/A N/A			n t	50	 	122	h r
B Y 240V	0C 26229 None			i a	40		104	e n
Fa	an Status			r	30		86	h e
FAN 1	2 3			d	20		68	i
3300	3240 3240 RPM			e		'		С

Figure 6-9 Display Power Supply Status Screen

Last Command: dsppwr

Next Command:

Displaying Connection Status

The endpoints and status of each connection that terminates on a node can be displayed using the Display Connections (**dspcons**) command and associated screen. This lists the connections by number and remote node. It also displays the status, OK or failed, and the Class of Service assigned. If desired, a filter can be applied so that this screen displays only certain types of connections, for example (Options: -v,-d,-a,-atfr,-g,+d,-abit,-fabit,-fail, nodename, -down,start_channel). See Figure 6-10 for an example of a typical Display Connections (**dspcons**) command screen.

bpxb	VT YourI	D:1 BPX 15	8.1.1	Dec.	9 1995	15:17	PS1
Local	Remote	Remote		Only	Route		
Channel	NodeName	Channel	State	atfr	Avoid	COS	0
5.2.6.100	bpxb	13.2.10.1000	Failed	cbr			
5.2.6.101	bpxb	13.2.10.1001	Failed	abr			
10.1.1.1	bpxa	13.1.1.1	Ok	abr		0	L
10.1.1.5	bpxb	10.1.1.5	Ok	vbr			
10.1.7.*	bpxd	4.1.7.*	Ok	abr		0	L
10.1.9.*	bpxa	13.1.9.*	Ok	vbr		0	L
10.1.10.10	bpxa	13.1.10.10	Ok	cbr		0	L
10.1.11.*	bpxa	13.1.11.*	Ok	abr		0	L
10.1.17.200	bpxa	13.1.17.201	Ok	abr		0	L
10.1.23.102	bpxd	4.1.23.102	Ok	abr-Grp		0	R
10.1.23.103	bpxd	4.1.23.103	Ok	abr-Grp		0	R
10.1.23.104	bpxd	4.1.23.104	Ok	abr-Grp		0	R
10.1.23.105	bpxd	4.1.23.105	Ok	abr-Grp		0	R

Figure 6-10 Display Connections Screen

This Command: dspcons -atfr

Continue?

Maintenance (Events) Log

A record of all events is kept in each node as well as in the StrataView Plus NMS. This Event Log is useful in maintaining the network as it lists in chronological order, all network events, and displays the alarm/event category, major, minor, information, etc.

You can use the HP OpenView Event Browers to display a network-wide list of events and alarms or filter the list as desired. Attrnatively, the dsplog command can be used at any selected node to observe an event log for that particular node as indicated in Figure 6-11. The node's log database can generally hold events for approximately 30 days after which the most recent log entry replaces the oldest entry.

Figure 6-11 Event Log Screen for a Node

bpxa		VT	YourID:1	BPX 15	8.1.1	Dec.	9	1995	15:	:33	PST
Most re	ecent lo	og entr	ies (most re	ecent at top)							
Class	Descrip	ption						Date		Tin	ne
Info	User Yo	ourID l	ogged in (Vi	rtual Termina	al)			12/09	/95	15:	33:29
Info	User r	ichard	logged out (Virtual Termi	inal)			12/09	/95	15:	05:55
Info	User r	ichard	logged in (V	/irtual Termin	nal)			12/09	/95	15:	05:32
Info	User ra	achel l	ogged out (V	/irtual Termin	nal)			12/09	/95	14:	57:42
Info	User ra	achel l	ogged in (Vi	rtual Termina	al)			12/09	/95	14:	57:17
Clear	Communi	ication	Break with	bpxb Cleared				12/08	/95	16:	31:22
Minor	Commun	ication	Break with	bpxb				12/08	/95	16:	31:12
Info	User St	trataCo	m charlie in	(Local)				12/08	/95	16:	25:14
Info	User St	trataCo	m nancy out	(Local)				12/08	/95	16:	09:06
Info	User St	trataCo	m evans out	(Virtual Terr	ninal)			12/08	/95	15:	46:15
Info	User St	trataCo	m nancy in (Virtual Termi	inal)			12/08	/95	15:	46:04
Info	Clock s	switch	to Line 5.1	of bpxb via 1	FRK 5.1			12/08	/95	15:	34:59
Clear	TRK 5.2	l ok						12/08	/95	15:	34:28

This Command: dsplog

Continue?

Display of Network Trunk Loading

IPX/IGX/BPX system software automatically assigns connections to the network trunks as they are added. If there is a choice between several trunks to the same destination, the software will attempt to balance the loading on the trunks. If an attempt to add a connection fails, it often is the result of inadequate bandwidth available for the connection.

Trunk loading on each trunk can be displayed by using the Display Trunk Loading (dspload) command, which displays the loading in both directions of transmission for each of the packet types. This screen is useful for determining the capacity of each trunk to accommodate additional frame relay traffic. Figure 6-12 illustrates a typical trunk loading screen.

bpx1	a		VT	YourID	:1	BPX 1	58	.1.1	Dec.	9	1995	15:38	PST
Trun	k load	ds fo	r node	'bpx1'									
	Unit	s	Used		Availa	ole	Reser	ved					
TRK	Xmt	Rcv	Xmt	Rcv	Xmt	Rcv	Xmt	Rcv					
1.1	Cell	Cell	88320	88304	6688	6704	992	992					
1.2	Cell	Cell	63808	63808	31200	31200	992	992					
1.3	Cell	Cell	0	0	95008	95008	992	992					
5.1	Cell	Cell	273008	273008	79200	79200	992	992					
5.2	Cell	Cell	0	0	352208	352208	992	992					
6.1	Cell	Cell	0	0	352208	352208	992	992					
6.2	Cell	Cell	326592	326592	25616	25616	992	992					

Figure 6-12 Display Trunk Loading

Last Command: dspload

Next Command:

System Troubleshooting Tools

There are a number of manually-initiated tests that can be performed from the NMS console to assist in system troubleshooting. These tests may be included in a job so they can be scheduled to run remotely at a specified time if desired.

User-initiated Tests

There are several user-initiated tests that can be used to diagnose system problems. These tests are self-contained in that they do not require the use of external test equipment. They also do not require the operator to place a loopback at the far end to test both directions of transmission. These tests are listed in Table 6-1.

There are also several display commands that can be used to obtain information that may be helpful in troubleshooting system problems. These are also listed in Table 6-1.

Command	Description
Test Connection (tstcon)—frame relay	Performs a bi-directional test of the specified frame relay connection or range of connections by inserting an IPX-generated test pattern and comparing the returned pattern with the pattern transmitted. A pass or fail indication appears next to the tested connection in the Display Connections screen.
Test Connection (tstcon)—data	Same as above except for synchronous data connections.
Test Connection (tstcon)—voice	Same as above except for voice connections.
Test Delay (tstdelay)—frame relay	Measures the round-trip delay over the selected frame relay connection.
Test Port (tstport)—frame relay	Tests the operation of the selected frame relay port on the node.
Test Port (tstport)- data	Same as above except for synchronous data ports.
Display Connection States (dspconst)	Displays in real-time the status of all voice connections terminating at a specified node.
Display Breakout Box (dspbob)—frame relay	Displays in real-time the status of data and control leads on selected frame relay connection.
Display Breakout Box (dspbob)—data	Same as above for synchronous data connections.
Display Breakout Box (dspbob)—trunk	Same as above for network subrate trunks.
Display Buses (dspbuses)	Displays the status of the IPX system buses.
Display Slot Errors (dspsloterrs)	Displays any data errors associated with the slots in a BPX node.
Display Slot Alarms (dspslotalms)	Displays any alarms associated with the slots in a BPX node.
Display Trunk Errors (dsptrkerrs)	Displays any data errors associated with the network trunks connected to a node.

Table 6-1 System Troubleshooting Commands Available

Loopback Tests

There are also various loopback paths that can be set up to help diagnose transmission problems. They rely on using external test equipment to provide the source of a test signal. The available loopback commands are listed in Table 6-2. Figure 6-13 illustrates the various loopback paths using, in this example, a frame relay card set (FRP/FRI) in an IPX node.

A local loopback path (LL) is set up in the local node at the PAD card (FRP) associated with the port or connection to be tested. A test signal applied to the input passes through the associated Interface Card (FRI), is sent to the Frame Relay PAD card (FRP) over the system bus where it is looped back towards the input. This tests the cabling and the local node processing of the signal.

Command	Description
Add Local Loopback (addloclp) —frame relay port	Adds a loopback path at the frame relay port from the transmit side back to the receive side at the local node.
Add Local Loopback (addloclp)—frame relay connection	Does the same as above only for an individual frame relay connection.
Add Local Loopback (addloclp)—data	Adds a loopback path at the synchronous data port from the transmit side back to the receive side at the local node.
Add Local Loopback (addloclp) —voice	Adds a loopback path for an individual voice channel on a circuit line at the local node.
Add Remote Loopback (addrmtlp)—frame relay port	Adds a loopback path at the frame relay port from the transmit side back to the receive side at the remote node.
Add Remote Loopback (addrmtlp)—frame relay connection	Does the same as above only for an individual frame relay connection.
Add Remote Loopback (addrmtlp)—data	Adds a loopback path at the synchronous data port from the transmit side back to the receive side at the remote node.
Add Remote Loopback (addrmtlp) —voice	Adds a loopback path for an individual voice channel on a circuit line at the remote node.
Add External Loopback (addextlp)—data	Activates a near end or far end loopback on an external device, such as a DSU, connected to a synchronous data port.

Table 6-2	System Loopback Tests
-----------	-----------------------

A remote loopback path (RL) is set up in the remote node also at the PAD card (FRP). But, in this case, the signal travels over the network and through the remote node processing equipment but does not include the remote node Interface Card (FRI) or associated cabling. These components would be tested using another local loopback at the remote node.

The external loopback command finds limited use in data applications where an external data interface unit (DSU or CSU) is attached to the local node data interface card, illustrated by the SDI card in Figure 6-13. The local node transmits the appropriate loopback codes out the circuit line towards the external device and then sets up the appropriate loopback path.





Connection Testing

System software includes a Test Connection (**tstcon**) command for testing network connections. This test is initiated by the network operator from the NMS console and can be performed at any time but it momentarily interrupts traffic on the connection during the test. Testing a connection should be performed only when an alarm has been reported from the connection or during off-hours.

Test Connection tests both directions of transmission from end-to-end and displays a pass or fail indication for each connection tested. The test may be specified for a single connection or for a group of connections. The operator may specify a single connection, all connections, all connections of a particular type (voice, data, or frame relay), or a starting and ending connection number.

Figure 6-13 Network Loopback Paths

In addition to testing the connection, the Test Connection routine will attempt to isolate and repair any failure it detects. The controller card at the node where the Test Connection (**tstcon**) command is issued instructs the service card to build packets containing special test frames. These packets are sent across the network to the terminating node, which depacketizes them, repacketizes the frame, and sends them back to the originating node where the returned frame is analyzed.

If the returned test pattern is incorrect, the system goes into an automatic fault isolation mode. Controllers in the various nodes along the connection route communicate with each other over an overhead message channel separate from the normal circuits.

The test pattern continues to be transmitted and analyzed at each node along the path as it is transmitted and as it is received until the failed network element is identified. Redundant cards may be switched into operation and routing tables in associated network trunk cards may be reprogrammed in an attempt to correct the problem. If all else fails, the suspected path and/or network component is then reported to the network manager (NMS).

External Device Window

External devices connected to network nodes, such as bridges, routers, or sub-rate multiplexers may be accessed through the NMS Window command. This feature provides a direct command line interface to external devices from the NMS console. Depending on the capability of the external device, it is often possible to report status and alarms and to control or configure the device through an RS232 port connection.

Figure 6-14 illustrates a Window display of a router connected to the local node. In this example, the window is used to initiate a ping of the router connection.

```
Figure 6-14 NMS Window to a Local Router
```

```
Protocol [ip]:
Target IP address: 192.9.202.1
Repeat count [5]:
Datagram size [100]:
Timeout in seconds [2]:
Extended commands [n]:
Type escape sequence to abort. ^^
Sending 5, 100-byte ICMP Echos to 192.9.202.1, timeout is 2 seconds:
. . . . .
Success rate is 100 percent
```

Network Statistics

StrataView Plus collects network statistical data on the operation of the network and stores them in its database. They are available for display on the StrataView Plus console in either tabular form or as bar charts. Statistics can be a useful source of information for troubleshooting problems that do not necessarily cause a major or minor alarm indication or for locating intermittent failures that may occur at random.

There are four classes of statistics:

- Trunk statistics.
- Line statistics.
- Connection statistics.
- Frame Relay port statistics.

Table 6-3 lists the statistics categories and the general nature of the statistics collected in each category. Note this is not a complete list of statistics but merely indicates some of the various conditions monitored. Refer to the *StrataView Plus Operators Guide* for a complete listing.

Most statistics are collected on-demand and must be enabled by the system operator. The operator can set the collection interval, the sampling times, and the number of collection buckets to tailor the statistics for either long-term network performance evaluation or short term for network troubleshooting.

Statistics Category	Types of Statistics
Trunk statistics	Various trunk errors, bipolar violations, frame bit errors, loss of signal, etc.
	Packet errors and out of frame.
	FastPackets and ATM cells of various types transmitted/dropped.
	Transmitted ATM cell counts.
	Received ATM cell counts.
	Cells with CLP and EFCN set.
	ATM header error counts
	DS3 PLCP error counts.
	Bdata queue dropped cells.
Line statistics	Various circuit line errors, bipolar violations, frame bit errors, loss of signal, etc.
Connection statistics	Packets transmitted and received.
	Transmitted and received data bytes.
	Frame relay frames transmitted/discarded.
	Frames transmitted with FECN or BECN or DE set.
	Packets with CLP bit set dropped.
	Seconds in service.
Frame Relay Port	Frames transmitted and received.
	Bytes transmitted and received.
	Frames received with CRC or other errors
	Frames discarded at the connection ingress
	Frames discarded at the connection egress
	Frames discarded at the port egress
	LMI messages sent or dropped for various errors.
	DE frames dropped.

Table 6-3 Typical Statistics Collected