

Order Frame Relay Service

To use a Cisco router with Frame Relay, you must order Frame Relay service from your telephone company. To do this, order basic telephone service with the Frame Relay service and billing options you want. When your Frame Relay service has been installed, plug a modem into the phone jack and connect the modem to your computer.

[Click here for information about configuring your modem.](#)

<HR>

Continue with the next step in the process.

[Return to ClickStart Home Page](#)

