

Terminal Setting Commands

This chapter describes the commands used for configuring the terminal emulation software.

set baud

To configure the baud rate for the console port, use the **set baud** command.

set baud {1200 | 2400 | 9600 | 19200 | 38400}

Syntax Description

1200	Configures the console port for 1200 baud.
2400	Configures the console port for 2400 baud.
9600	Configures the console port for 9600 baud.
19200	Configures the console port for 19200 baud.
38400	Configures the console port for 38400 baud.

Default
9600

Command Mode
System level

Example

The following example configures the console port for 2400 baud:

```
Host> set baud 2400
```

set screen

To set the maximum number of lines that will be displayed on your terminal, use the **set screen** command.

set screen *lines*

Syntax Description

lines Maximum number of lines that will be displayed on your terminal. Must be between 2 and 128.

Default

20

Command Mode

System level

Example

The following example configures the terminal to display 30 lines at once:

```
Host> set screen 30
```

set screen
