

# Introduction

---

## Introduction

This manual provides installation instructions for the BPX.

For additional information on the BPX, including cabling descriptions, refer to the *BPX Reference Manual*. For a description of the commands used to operate a BPX, refer to the *Command Reference Manual*. Refer to the *System Manual* for system and network information. Refer to the StrataView Plus manuals for information on network management.

