
CPU Bus
R4600/R4400 Init. Pins
R4600/R4400
CPU Interface
R4600/R4400
Initialization
Address and
Command Fifo
Address and
Command Fifo
CPU Memory
Read and Writes
Graphics DMA
Master
Memory Controller
Memory
GIO Slave
GIO Arbiter
GI064 Bus
GIO64 Bus
Requests and Grants