# ClickStart Home Page

ClickStart lets you configure a Cisco 1003, Cisco 1004, or Cisco 1005 router. You can also use ClickStart to monitor any Cisco router.

These pages describe how to configure a router so you can connect a small office or home PC to the Internet or another network. To configure your router using ClickStart, you do not need to learn all about networks and routers.

### Configure a Cisco 1003 or Cisco 1004 ISDN Router

To configure a Cisco 1003 or Cisco 1004 ISDN router, follow these links:

- Understand How ClickStart Works.
- Order ISDN Service.
- Prepare to Configure an ISDN Router
- Verify the TCP/IP configuration on your Windows 3.11, Windows 95, or Macintosh PC, or prepare to configure from a UNIX workstation.
- Set Up the Router.
- Configure the Router.
- Test Your Router's Configuration.

## Configure a Cisco 1005 Frame Relay Router

To configure a Cisco 1005 router for Frame Relay, follow these links:

- Understand How ClickStart Works.
- Order Frame Relay Service.
- Prepare to Configure a Frame Relay Router.
- Verify the TCP/IP configuration on your Windows 3.11, Windows 95, or Macintosh PC, or prepare to configure from a UNIX workstation.
- Set Up the Router.
- Configure the Router.
- Test Your Router's Configuration.

## Configure a Cisco 1005 Asynchronous Serial Router

To configure a Cisco 1005 router with an asynchronous serial line, follow these links:

- Understand How ClickStart Works.
- Order Asynchronous Serial Service.
- Prepare to Configure an Asynchronous Serial Connection.
- Verify the TCP/IP configuration on your Windows 3.11, Windows 95, or Macintosh PC, or prepare to configure from a UNIX workstation.
- Set Up the Router.
- Configure the Router.
- Test Your Router's Configuration.

#### Monitor a Router

You can also use ClickStart to monitor any router running Cisco IOS Release 11.0(6) or later, or Cisco IOS Release 11.1(2) or later.

#### For More Details

For detailed information about how ClickStart works, read this technical information.

<HR>

If you have comments, send e-mail to cs-html@cisco.com.

<HR>

Visit Cisco Connection Online (CCO).